

[Manuals.plus](#) /

› [OlarHike](#) /

› OlarHike Signature Collection Queen Air Mattress User Manual

OlarHike AMH7V103

OlarHike Signature Collection Queen Air Mattress User Manual

Model: AMH7V103

PRODUCT OVERVIEW

The OlarHike Signature Collection Queen Air Mattress is designed for comfort and durability, featuring a built-in pump for easy inflation and deflation. Its 18-inch height provides a comfortable sleeping experience for home use, guests, or camping.

Key features include:

- **Silky Smooth Foam Topper:** Experience cloud-like comfort with a plush silk foam top layer.
- **Durable Construction:** Crafted with PVC coils for robust support, anti-leak fabric, and 50D milk silk fabric for enhanced comfort.
- **Built-in Pump:** Effortless self-inflation and deflation for convenient setup and storage.
- **Tailored Comfort:** PVC coils conform to your body's curves for personalized support.
- **Seamless Storage:** Includes a convenient carrying bag for easy transport and organization.

OlarHike SIGNATURE COLLECTION

THE ONLY AIR MATTRESS YOU WILL EVER NEED.



Figure 1: OlarHike Signature Collection Air Mattress in use.

Initial Expansion (First Use Only)

HOW TO INFLATE & DEFLATE SPONGE TOPPER



Inflation

1. Ensure the airbed is laid on a level surface, free from stones and sharp objects, to prevent damage.
2. Locate the built-in electric pump on the side of the mattress.
3. Plug the power cord into a standard electrical outlet.
4. Turn the control dial to the "INFLATE" position. The pump will begin to inflate the mattress.
5. Stop inflating once the airbed is fully expanded and firm to your desired comfort level. Do not over-inflate.
6. Once inflated, ALWAYS turn the control dial to the "OFF" (middle) position to prevent deflation.
7. Store the power cord in the integrated storage compartment on the pump unit.

PUT YOUR WORRIES TO REST

A NEW INNOVATIVE DESIGN WITH YOUR COMFORT,
SUPPORT AND BEST SLEEP IN MIND.



EXTENDED CORD INSIDE STORAGE
COMPARTMENT FOR CONVENIENT
SET UP AND TAKE DOWN.



BUILT-IN
SPONGE CUSHION



Figure 3: Built-in pump and power cord storage.

OPERATING INSTRUCTIONS

Adjusting Firmness

The built-in pump allows for easy adjustment of the mattress firmness. If the mattress feels too soft, simply turn the dial to "INFLATE" for a short period to add more air. If it feels too firm, briefly turn the dial to "DEFLATE" to release some air until your desired comfort is achieved.

Optimal Top Cushion Usage

For optimal top cushion usage, please ensure to remove the air nozzle during use to allow the silk foam topper to fully expand and provide maximum comfort.

WHERE LUXURY MEETS DURABILITY



*LAYERS DO NOT
ACTUALLY PEEL OFF

THIS COLLECTION FEATURES A SILK FOAM TOPPER WITH
FIGURE-FITTING TECHNOLOGY FOR EXCEPTIONAL COMFORT.

Figure 4: Multi-layer construction for enhanced comfort and durability.

MAINTENANCE

Deflation and Storage

1. To deflate the mattress, turn the control dial on the built-in pump to the "DEFLATE" position. The pump will actively remove air from the mattress.
2. Once fully deflated, roll up the airbed.
3. Secure the rolled mattress with the included strap.
4. Place the deflated and rolled mattress into the convenient carrying bag for seamless storage and transportation.



Figure 5: Steps for deflating and storing the air mattress.

Temperature Considerations

Avoid exposing your airbed to extreme temperatures (hot or cold). In hot weather, the air inside will expand, requiring you to let out some air to prevent overpressure and potential popping. In cold weather, the air will contract, which may cause the airbed to lose some pressure and require additional inflation.

Pump Care

- Do not expose the electric pump to moisture.
- Never run the pump for longer than 10 minutes at a time. Allow the motor to cool down for 7 minutes before using it again.
- Disconnect the plug when the pump is not in use.

TROUBLESHOOTING

Mattress Losing Air

If your mattress appears to be losing air, first ensure that the valve at the pump is ALWAYS turned to the "OFF" (middle) position after inflation. Also, check the airbed for any visible holes, rips, or tears. While the mattress is designed with anti-

leak fabric, punctures can occur from sharp objects.

Contacting Customer Support

If you experience persistent issues or believe your product is defective, please refer to the warranty information and contact OlarHike customer support. Some customers have reported successful resolutions, including full refunds or replacements, by contacting the manufacturer directly.

SPECIFICATIONS

Size	Queen
Model Name	AMH7V103
Product Dimensions	80"L x 60"W x 18"Th
Item Weight	21.6 pounds
Material	Silk Foam Topper, PVC Coils, 50D Milk Silk Fabric
Special Features	Portable, 18" Extra Tall, Silk Foam Topper, Built-In Pump, Leakproof
Included Components	User Guide, Carry Bag, Queen Air Mattress With Built In Pump
Water Resistance Level	Waterproof
Item Firmness Description	Firm

WARRANTY AND SUPPORT

Peaceful Purchase Guarantee

Your OlarHike air mattress comes with a special 2-year protection, designed to provide peace of mind. The brand is dedicated to your satisfaction and ensuring your product stays in top-notch condition.

User Guide and Additional Support

For detailed instructions and further assistance, please refer to the official[User Guide \(PDF\)](#). OlarHike also provides U.S.-based customer support for any inquiries or issues.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question