

UPBRIGHT Rotai ETF004M1 Power Supply

UpBright 24V AC/DC Adapter
INSTRUCTION MANUAL FOR ROTAI ETF004M1 FOOT MASSAGER

1. Introduction

This manual provides instructions for the safe and effective use of the UpBright 24V AC/DC Adapter. This power supply is specifically designed for compatibility with the Rotai ETF004M1 Heated Shiatsu Vibration Smart Foot Massager, as well as models J652-2403000UX and J6522403000UX. Please read this manual thoroughly before use to ensure proper operation and to prevent damage to the adapter or connected device.

2. Setup


Follow these steps to properly set up your UpBright 24V AC/DC Adapter:

- Verify Compatibility:** Ensure that your device, such as the Rotai ETF004M1 foot massager, requires a 24V DC power input and that the connector type matches the adapter's output plug. This adapter provides 24V DC output.
- Connect to Device:** Insert the DC output plug of the adapter firmly into the power input port of your Rotai ETF004M1 foot massager.
- Connect to Power Outlet:** Plug the AC input cord of the adapter into a standard electrical wall outlet (100-240VAC, 50/60Hz). The adapter is designed for worldwide input voltage compatibility.
- Power On:** Once connected, your device should be ready for operation.



Image 1: The UpBright 24V AC/DC Adapter with its attached DC output cable and detachable AC input power cord.

Come With A Suitable AC Power Cord (Only One)
to Fit Your Country/Area



THIS PRODUCT COMES WITH A UPBRIGHT®

LIMITED WARRANTY CERTIFICATE
+ UpBright® LIMITED WARRANTY



Image 2: Examples of different AC power cord plug types (US, EU, UK, AU) that may be supplied with the adapter, ensuring compatibility in various regions.

3. Operating Instructions

The UpBright AC/DC Adapter functions as a power source for compatible electronic devices. Once properly connected, it converts the alternating current (AC) from your wall outlet into direct current (DC) required by your device.

- **Automatic Operation:** The adapter operates automatically when plugged into a power source and connected to a device. No manual controls are required for its basic function.
- **Safety Features:** This adapter includes built-in protection mechanisms:
 - **OVP (Over Voltage Output Protection):** Protects your device from excessive voltage output.
 - **OCP (Over Current Output Protection):** Safeguards against excessive current flow.
 - **SCP (Short Circuit Output Protection):** Prevents damage in case of a short circuit.
- **Environmental Conditions:** Use the adapter in a well-ventilated area. Avoid covering the adapter during operation to prevent overheating.

4. Maintenance

Proper care ensures the longevity and reliable performance of your adapter:

- **Cleaning:** Disconnect the adapter from both the power outlet and your device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly wrapping the cables to prevent damage.
- **Inspection:** Periodically inspect the adapter and cables for any signs of damage, such as frayed wires, bent pins, or cracks in the casing. Do not use a damaged adapter.

5. Troubleshooting

If you encounter issues with your UpBright AC/DC Adapter, consider the following:

- **Device Not Powering On:**
 - Ensure the adapter is securely plugged into both the wall outlet and your device.
 - Verify that the wall outlet is functional by testing it with another appliance.
 - Check for any visible damage to the adapter or cables.
- **Adapter Overheating:**
 - Ensure the adapter is in a well-ventilated area and not covered.
 - Confirm that the connected device's power requirements do not exceed the adapter's specifications.
- **Intermittent Power:**
 - Check all connections for looseness.
 - Inspect cables for any signs of internal damage or fraying.

If troubleshooting steps do not resolve the issue, discontinue use and contact customer support.

6. Specifications

Feature	Detail
---------	--------


Feature	Detail
Input Voltage	100-240VAC, 50/60Hz (Worldwide Compatible)
Output Voltage	24V DC
Compatibility	Rotai ETF004M1 Heated Shiatsu Vibration Smart Foot Massager, J652-2403000UX, J6522403000UX
Protection Features	OVP (Over Voltage Output Protection), OCP (Over Current Output Protection), SCP (Short Circuit Output Protection)
Product Dimensions	6 x 3 x 2 inches
Item Weight	10 ounces
Manufacturer	UpBright
Color	Black
Form Factor	Compact

7. Warranty & Support

Warranty Information:

- UpBright offers a **30-day refund policy** from the date of purchase.
- A **24-month exchange warranty** is provided for defective units.
- Please retain your proof of purchase for warranty claims.

Come With A Suitable AC Power Cord (Only One)
to Fit Your Country/Area



THIS PRODUCT COMES WITH A UPBRIGHT®

LIMITED WARRANTY CERTIFICATE



Image 3: An illustration depicting a warranty certificate and a product warranty seal, indicating the product's coverage.

Customer Support:

For any questions, concerns, or warranty claims, please contact UpBright customer support through your retailer or the official UpBright channels. Refer to your purchase documentation for specific contact details.

© 2023 UpBright. All rights reserved. Information in this manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0C696VTLX>

More documents and user manuals: <https://manuals.plus/>