

Reebok RB3016

Reebok Work Zig Pulse Work Sneaker CT Men's Oxford User Manual

Model: RB3016

INTRODUCTION

The Reebok Work Zig Pulse Work Sneaker CT Men's Oxford is engineered to provide exceptional comfort and protection throughout your workday. Featuring an innovative ZigTech outsole for superior energy dispersion and shock absorption, these athletic work shoes are designed to keep you energized. The composite toe and TPU stabilizer offer essential safety and support, making them ideal for demanding work environments.

PRODUCT FEATURES

- Work sneaker from Reebok
- Textile upper for breathability
- XTR composite toe for impact protection
- Lace-up front closure for a secure fit
- Cushioned MemoryTech Massage 2.0 footbed for comfort
- Zigtech EVA Midsole with Rubber SR Pads for energy return and slip resistance
- 100% Non-Metallic construction
- Dual Resistor (SD10) for static dissipative properties
- Extra Wide Toe for enhanced comfort
- TPU Stabilizer for pressure distribution and arch support

PRODUCT IMAGES



Front-side view of the Reebok Work Zig Pulse Work Sneaker in black and red, showcasing the distinctive ZigTech sole.



Front view of the sneaker, highlighting the composite toe and lacing system.



Bottom view of the shoe, displaying the Zigtech EVA Midsole with black rubber SR pads for enhanced grip.



Side profile of the sneaker, showing the breathable mesh upper and the full length of the ZigTech sole.

SETUP

Proper setup ensures maximum comfort and safety from your Reebok Work Zig Pulse Work Sneakers.

1. **Unboxing:** Remove shoes from packaging. Inspect for any visible damage or defects.
2. **Initial Fit:** Try on both shoes with the type of socks you typically wear for work. Ensure there is adequate space (about a thumb's width) between your longest toe and the end of the shoe.
3. **Lacing:** Lace the shoes securely but not too tightly. Adjust the laces to achieve a snug fit around your foot without causing pressure points.
4. **Break-in Period:** While designed for comfort, a short break-in period may be beneficial. Wear them for shorter durations initially to allow the shoes to conform to your feet.

OPERATING INSTRUCTIONS

These sneakers are designed for daily use in work environments requiring safety footwear. Follow these guidelines for optimal performance:

- **Daily Wear:** Wear your Zig Pulse Work Sneakers for their intended purpose as protective work footwear.
- **Surface Awareness:** While the outsole features slip-resistant (SR) pads, always exercise caution on wet, oily, or uneven surfaces.
- **Regular Inspection:** Before each use, quickly inspect the shoes for any signs of wear, especially on the sole and toe area, to ensure continued protection.
- **Comfort Management:** If you experience discomfort, ensure your lacing is not too tight or too loose. The MemoryTech Massage 2.0 footbed is designed for cushioning, but individual comfort needs may vary.

MAINTENANCE

Proper care will extend the life and maintain the performance of your Reebok Work Zig Pulse Work Sneakers.

- **Cleaning:** For the textile and mesh upper, gently wipe with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners.
- **Drying:** Allow shoes to air dry naturally at room temperature. Do not use direct heat sources like radiators or hair

dryers, as this can damage materials.

- **Storage:** Store shoes in a cool, dry place away from direct sunlight when not in use.
- **Insole Care:** The MemoryTech Massage 2.0 footbed can be removed for airing out if needed. Do not machine wash insoles.
- **Sole Care:** Regularly check the outsole for embedded debris that could affect slip resistance. Clean as necessary.

TROUBLESHOOTING

Problem	Possible Cause / Solution
Discomfort or pressure points	Ensure correct size and width. Adjust lacing for a comfortable fit. Allow for a short break-in period. Consider trying different socks or aftermarket insoles if persistent.
Soles or upper showing premature wear	While durable, extreme conditions or improper use can accelerate wear. Ensure shoes are used for their intended purpose. Follow maintenance guidelines. If wear is excessive and unexpected, refer to warranty information.
Reduced slip resistance	Check outsole for embedded debris or excessive wear. Clean the sole thoroughly. Ensure surfaces are not beyond the shoe's slip-resistant capabilities.
Foot odor	Ensure shoes are fully dry between uses. Remove insoles to air out. Use odor-absorbing inserts or sprays if necessary.

SPECIFICATIONS

Attribute	Value
Product Dimensions	11.9 x 8.1 x 5 inches; 1.5 Pounds
Item Model Number	RB3016
Department	mens
Date First Available	September 8, 2021
Manufacturer	Reebok Work
ASIN	B0CLTCWL8Z
Fabric Type	Leather/Mesh
Origin	Imported
Sole Material	Rubber
Outer Material	Mesh

WARRANTY AND SUPPORT

For specific warranty information regarding your Reebok Work Zig Pulse Work Sneakers, please refer to the

documentation included with your purchase or visit the official Reebok Work website. For further assistance, product inquiries, or support, please contact Reebok Work customer service directly.

You can often find contact details on the Reebok Work official website or through the retailer where the product was purchased.

© 2025 Reebok Work. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question