

[Manuals.plus](#) /

› [Feonase](#) /

› Feonase Queen Lift Up Storage Bed Frame Instruction Manual

Feonase 821B3


Feonase Queen Lift Up Storage Bed Frame

MODEL: 821B3

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your Feonase Queen Lift Up Storage Bed Frame. This bed frame features a hydraulic lifting system for ample under-bed storage, an integrated charging station in the headboard, and a sturdy, noise-free design with wooden slat support. Please read these instructions carefully before beginning assembly and retain for future reference.

1




Strong Structural

2

Easy to Assemble



3



Noises Free

Image: The Feonase Queen Lift Up Storage Bed Frame, showcasing its upholstered wingback headboard and overall design.

Safety Information

- **Weight Capacity:** Do not exceed the maximum weight capacity of **1000 lbs** for the bed frame.
- **Assembly:** Keep children and pets away from the assembly area. Ensure all hardware is securely tightened before use.
- **Hydraulic System:** The hydraulic lifting mechanism is powerful. Keep hands and fingers clear when lifting or lowering the mattress platform. Always use the designated lifting strap.
- **Mattress Placement:** Ensure the mattress is properly seated on the frame before operating the hydraulic lift. The weight of the mattress is necessary for the hydraulic system to function correctly.
- **Charging Station:** Do not overload the electrical outlets. Keep liquids away from the charging station to prevent electrical hazards. Disconnect from power when not in use or during cleaning.
- **Moving the Bed:** When moving the bed, lift it rather than dragging to prevent damage to the frame and flooring.

Package Contents

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Headboard with integrated charging station
- Side Rails (Left and Right)
- Footboard
- Wooden Slats and Slat Holders
- Hydraulic Lifting Mechanism (Gas Struts and Support Frame)
- Hardware Pack (Bolts, Screws, Washers, Allen Wrench)
- Handheld Lifting Strap
- Anti-Fall Device for mattress retention
- Instruction Manual

Assembly Instructions

Assembly is designed to be straightforward. All parts are numbered, and clear instructions are provided. It is recommended to assemble with two people.

1. **Preparation:** Unpack all components and lay them out on a clean, soft surface (e.g., a rug or blanket) to prevent scratches. Identify each part by its corresponding number.
2. **Assemble the Headboard:** Attach any necessary support brackets or legs to the headboard as indicated in the detailed diagram.
3. **Connect Side Rails:** Securely attach the side rails to the headboard and footboard using the provided bolts and an Allen wrench. Do not fully tighten all bolts until the frame is mostly assembled to allow for minor adjustments.
4. **Install Hydraulic Lifting Mechanism:** Mount the hydraulic gas struts and the metal support frame to the bed frame according to the diagrams. Ensure the mechanism moves freely.
5. **Place Wooden Slats:** Insert the wooden slats into their designated holders on the metal support frame. Ensure the EVA silent rod is correctly positioned to prevent noise.
6. **Install Charging Station:** Connect the power cord from the headboard's charging station to a wall outlet.
7. **Final Tightening:** Once all components are in place and aligned, fully tighten all bolts and screws.

Storage Headboard with Charging Station



110V/12A
2AC Outlets



5V/2A
2USB Ports



6.6-Feet
Power Cord

Image: Structural details highlighting strong construction, easy assembly points, and noise-free features.



Image: Components of the hydraulic lifting system, including the lifting strap and anti-fall device.

Operating Instructions

Hydraulic Lift Storage

The bed frame features a hydraulic lifting mechanism to access a spacious storage compartment beneath the mattress. This compartment offers approximately 10 inches of height, ideal for storing luggage, storage boxes, seasonal bedding, and shoes.

1. **To Lift:** Ensure the mattress is on the frame. Grasp the handheld lifting strap located at the foot of the bed. Gently pull upwards to engage the hydraulic system. The platform will lift smoothly.
2. **To Lower:** With the mattress on the frame, gently push down on the mattress platform. The hydraulic system will assist in a controlled descent. Ensure hands and fingers are clear of pinch points.




Image: Bed frame with mattress platform lifted, showing the spacious under-bed storage area.

Integrated Charging Station

The headboard includes a convenient charging station for your electronic devices.

- **Location:** The charging station is located on the top surface of the headboard.
- **Features:** It includes two 110V/12A AC outlets and two 5V/2A USB ports.
- **Usage:** Plug your devices directly into the available outlets or USB ports for convenient charging while in bed.



Image: Detail of the headboard's charging station with AC and USB ports.

Maintenance

- **Cleaning:** For upholstered parts, gently vacuum or wipe with a slightly damp cloth. Avoid harsh chemicals. For metal parts, wipe with a dry cloth.
- **Hardware Check:** Periodically (every 3-6 months) inspect all bolts and screws to ensure they remain tight. Re-tighten if necessary to maintain stability and prevent noise.
- **Hydraulic System:** Keep the hydraulic mechanism free of dust and debris. Do not apply lubricants unless specifically instructed by the manufacturer.

Troubleshooting

- **Bed Frame is Noisy:**
 - Ensure all assembly bolts and screws are securely tightened.

- Verify that the wooden slats are correctly seated in their holders and the EVA silent rod is properly installed between the slats and metal frame.

- **Hydraulic Lift is Difficult to Operate:**

- Confirm that a mattress is placed on the bed frame. The hydraulic system is designed to work with the weight of a mattress.
- Check for any obstructions preventing the mechanism from moving freely.

- **Charging Station Not Working:**

- Ensure the power cord from the headboard is securely plugged into a functional wall outlet.
- Check your home's circuit breaker for any tripped circuits.
- Avoid overloading the outlets with too many high-power devices.

Specifications



Image: Dimensional overview of the Feonase Queen Lift Up Storage Bed Frame.

Feature	Detail
Model Number	821B3
Size	Queen
Product Dimensions (L x W x H)	85.5" x 63" x 46"
Weight Capacity	1000 lbs
Material	Wood, Fabric, Iron
Color	Beige
Special Features	Charging Station, Geometric Design Headboard, Hydraulic Lifting
Box Spring Required	No
Charging Station Output	2 AC Outlets (110V/12A), 2 USB Ports (5V/2A)
Item Weight	124 pounds

Warranty and Support

Feonase provides a limited warranty for this product against manufacturing defects. For specific warranty details, claims, or if you require assistance with missing parts, assembly, or any other issues, please contact Feonase customer support through the retailer where the product was purchased. Please have your model number (821B3) and purchase information ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CRR5PFTW>

More documents and user manuals: <https://manuals.plus/>