

ABBIDOT AB-T30

ABBIDOT Dog Training Collar User Manual

Model: AB-T30

INTRODUCTION

This user manual provides detailed instructions for the safe and effective use of your ABBIDOT Dog Training Collar. Please read this manual thoroughly before operating the device to ensure proper functionality and the well-being of your pet. This training collar is designed to assist in modifying undesirable behaviors in dogs weighing between 8 and 120 lbs.

SAFETY INFORMATION

Your pet's safety and comfort are paramount. Always use the training collar responsibly and humanely. Improper use can lead to physical or psychological harm to your dog.

- Do not use this collar on puppies younger than 6 months old.
- Avoid leaving the collar on your dog for more than 12 hours per day to prevent pressure necrosis.
- Regularly check your dog's neck for signs of irritation or sores. If irritation occurs, discontinue use until the skin heals.
- The remote control features a built-in safety lock to prevent accidental stimulation. Always engage the safety lock when not actively training.
- This device is a training aid, not a punishment tool. Use it in conjunction with positive reinforcement training methods.

COMPONENTS AND PACKAGE CONTENTS

Upon opening the package, please verify that all components are present and in good condition.



Image: The ABBIDOT dog training collar system, including the remote control and the collar receiver.



Image: Detailed view of the ABBIDOT T30 training collar components, including the remote, collar, silicone caps, test light, and metal extension contacts.

Package Includes:

- Remote Transmitter
- Collar Receiver
- Adjustable Nylon Collar Strap
- USB-C Charging Cable
- Test Light Tool
- Short and Long Contact Points
- Silicone Conductive Caps
- User Manual (this document)

SETUP

1. Charging the Devices

Before first use, fully charge both the remote transmitter and the collar receiver. Use the provided USB-C charging cable.

- Connect the charging cable to the charging port on both devices.
- A full charge typically takes approximately 2 hours.
- The battery indicator on the remote and collar will show charging status.



Image: Illustration of the long-lasting battery life for the ABBIDOT remote and collar receiver.

2. Pairing the Remote and Receiver

The remote and receiver are typically pre-paired from the factory. If re-pairing is needed:

1. Ensure both devices are turned off.
2. Press and hold the On/Off button on the receiver until the indicator light flashes rapidly.
3. While the receiver light is flashing, press any mode button (Tone, Vibration, or Shock) on the remote.
4. The receiver light will stop flashing and remain solid, indicating successful pairing.

3. Fitting the Collar

Proper fit is crucial for effective and safe operation. The contact points must make direct contact with your dog's skin.



For Long/Short Fur Dogs



Comfort and Soft



Stand Wear and Tear

LIGHTWEIGHT E-COLLAR FOR 15~120 lbs



→ **Min 6 inches**

Max 27 inches →



Adjustable and Cuttable



Image: Demonstrates proper collar fit and adjustability for dogs weighing 15-120 lbs.

- Place the collar around your dog's neck, ensuring the receiver is positioned centrally under the chin or on the side of the neck.
- Adjust the strap so that you can comfortably fit two fingers between the collar and your dog's neck. It should be snug but not tight.
- For dogs with thick fur, use the longer contact points to ensure skin contact.



Image: Shows the different contact points available for various fur lengths, ensuring proper skin contact.

If your dog has very sensitive skin, consider using the silicone conductive caps over the contact points.


OPERATING THE COLLAR

The ABBIDOT training collar offers four humanized modes and a night safety light for comprehensive training.

Prevent Accidental Touch Design

ABBI-TES

Knob Type Gear With Safety Lock



Light



Vibration

(1~36 Levels)



Tone

(1~16 Levels)



General Stimulation
(1~15 Levels)



Boosted Stimulation
(16~36 Levels)



Image: Illustrates the remote control with its various modes (Light, Vibration, Tone, General Stimulation, Boosted Stimulation) and the ABBI-TES safety lock feature.

Remote Control Overview:

HIGH DEFINITION LCD

CLEAR DISPLAY IN OUTDOOR



Image: Close-up of the remote's high-definition LCD display, showing visibility in various lighting conditions and low power consumption.

Training Modes:

- **Tone Mode:** Produces an audible beep. Ideal for initial warnings or positive reinforcement. (9 tones available)
- **Vibration Mode:** Delivers a gentle vibration. Useful for gaining attention or as a mild correction. (36 levels)
- **Stimulation Mode:** Provides a static pulse. Used for more direct corrections. (36 levels, including General and Boosted)

Adjusting Levels:

Use the 'PUSH +' and 'PUSH -' buttons on the remote to adjust the intensity levels for Vibration and Stimulation modes. Start at the lowest level and gradually increase until your dog responds.

Safety Lock Feature (ABBI-TES):

The remote features a knob-type gear with a safety lock. Press down on the knob to lock the stimulation function, preventing accidental activation. This ensures safe handling when not actively training.

Night Safety Light:

Press the dedicated light button on the remote to activate the LED light on the collar receiver. This enhances visibility of your dog in low-light conditions, improving safety during evening walks or outdoor play.



Image: Demonstrates the tracking light design on the collar, which helps locate the dog after dark and increases visibility to traffic.

Multi-Dog Control:

The remote can control up to two collar receivers. Use the channel selection buttons (1/2) on the remote to switch between dogs.



Image: Illustrates the remote's capability to control two separate dog collars, indicated by channel selection 1 and 2.

Control Range:

The system offers a control range of up to 3300 feet (approximately 1000 meters) in open areas, providing ample freedom for training.



Image: Shows the IPX7 waterproof rating of the collar and the 3300ft control range of the remote.

MAINTENANCE

Cleaning:

- Wipe the collar receiver and remote with a damp cloth. Do not use harsh chemicals.
- Regularly clean the contact points to ensure proper conductivity.

Battery Care:

- Charge the devices when the battery indicator is low.
- For long-term storage, charge the devices to about 50% and store in a cool, dry place.

- Remote battery life: up to 35 days standby, 16 days work time.
- Collar receiver battery life: up to 25 days work time.



Image: Detailed graphic showing the battery life of the remote (16 days) and receiver (10 days).

Waterproofing:

The collar receiver is IPX7 waterproof, making it suitable for swimming and use in rainy conditions.**Note: The remote control is NOT waterproof.**

Your browser does not support the video tag.

Video: Demonstration of the ABBIDOT collar receiver's IPX7 waterproof capability, showing it submerged in water. Note that the remote control is not waterproof.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Collar not responding to remote	Low battery; Not paired; Out of range; Safety lock engaged	Charge both devices; Re-pair devices; Move closer to the dog; Disengage safety lock
Stimulation not felt by dog	Poor contact with skin; Level too low; Wrong contact points	Adjust collar fit; Increase stimulation level gradually; Use longer contact points for thick fur
Collar indicator light not working	Low battery; Device off	Charge collar; Turn on collar
Remote screen is blank	Low battery; Device off	Charge remote; Turn on remote

SPECIFICATIONS

- **Model Number:** AB-T30
- **Brand:** ABBIDOT
- **Item Weight:** 10.6 ounces (300 Grams)
- **Product Dimensions:** 5.91 x 4.33 x 0.04 inches
- **Material:** Plastic, Rubber
- **Color:** Black
- **Battery Type:** 2 Lithium Polymer batteries (included)
- **Waterproof Rating (Receiver):** IPX7
- **Control Range:** Up to 3300 feet (1000 meters)
- **Training Modes:** Tone (9 levels), Vibration (36 levels), Stimulation (36 levels)
- **Target Audience:** Dogs (8-120 lbs, >6 months old)

WARRANTY AND SUPPORT

For any questions, concerns, or technical assistance, please contact ABBIDOT customer support. You can find additional resources and contact information by visiting the official ABBIDOT store on Amazon:

[Visit the ABBIDOT Store](#)

A downloadable PDF version of the user manual is also available for your convenience:

[Download User Manual \(PDF\)](#)

© 2024 ABBIDOT. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question