

[Manuals.plus](#) /

> [Dowinx](#) /

> Dowinx Gaming Chair LS-6688 Instruction Manual

Dowinx LS-6688

Dowinx Gaming Chair LS-6688 Instruction Manual

Comprehensive guide for assembly, operation, maintenance, and troubleshooting.

INTRODUCTION

Thank you for choosing the Dowinx Gaming Chair LS-6688. This manual provides detailed instructions to ensure safe assembly, proper operation, and effective maintenance of your chair. Please read this manual thoroughly before use and retain it for future reference.

For the safety of young children, keep small extra pieces out of reach during assembly. If any parts are damaged during shipping, please contact our customer service for assistance. Always follow the assembly instructions carefully to ensure safe and proper use of the chair.

SAFETY INFORMATION

- Ensure all screws and bolts are tightened securely before using the chair.
- Do not stand on the chair or use it as a step stool.
- Avoid placing heavy objects on the chair's backrest or armrests.
- Do not expose the chair to direct sunlight or extreme temperatures.
- Keep the chair away from sharp objects to prevent damage to the upholstery.
- Maximum weight capacity: 350 pounds. Do not exceed this limit.

PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. Refer to the included parts list in your package.





Image: Main view of the Dowinx Gaming Chair LS-6688, showing its ergonomic design and footrest.

ASSEMBLY INSTRUCTIONS

Assembly typically requires two individuals and takes approximately 30-60 minutes. All necessary tools are included in the package. Follow the detailed step-by-step instructions provided in the printed manual.

1. **Base Assembly:** Attach the casters to the chair base. Insert the gas lift cylinder into the center hole of the base.
2. **Seat Assembly:** Secure the tilt mechanism to the underside of the seat cushion using the provided screws.
3. **Backrest Attachment:** Connect the backrest to the seat cushion using the side brackets and screws.
4. **Armrest Installation:** Attach the linkage armrests to the seat and backrest.
5. **Footrest Assembly:** Install the retractable footrest mechanism to the underside of the seat.
6. **Final Connection:** Place the assembled seat and backrest onto the gas lift cylinder.
7. **Cushion Placement:** Position the head pillow and lumbar support cushion.



Image: Components including the tilt mechanism, gas cylinder, chair base, and casters, essential for assembly.

OPERATING INSTRUCTIONS

1. Height Adjustment

To adjust the chair height, pull the lever located on the right side of the seat upwards. While pulling the lever, either lift your body weight off the seat to raise it, or apply downward pressure to lower it. Release the lever to lock the height.

2. Recline Function

The backrest can recline from 90° to 165°. Pull the lever on the left side of the seat upwards to unlock the backrest. Lean back to your desired angle and release the lever to lock it in place.

LAY FLAT WITH THE GENEROUS 165° OF RECLINE

Powered by Heavy-Duty Mechanisms




Image: A diagram showing the chair reclining from an upright working position to a fully flat resting position, highlighting the 165-degree recline capability.

3. Rocking Function

To enable the rocking function, pull the same lever used for height adjustment outwards. Push it inwards to lock the chair in an upright position. The rocking tension can be adjusted by turning the knob located underneath the seat.

4. Retractable Footrest

To extend the footrest, pull it out from underneath the seat. To retract, push it back in until it is fully stored.

5. Massage Lumbar Support

The lumbar support cushion features a massage function. Connect the USB cable from the cushion to any standard USB power source (e.g., computer, power bank, USB wall adapter) to activate the massage feature.

MEMORY FOAM HEADREST + MASSAGE FUNCTION

The combination of the two makes for unique, all-encompassing



Image: Close-up of the chair's headrest and lumbar support, indicating the massage function and memory foam properties.

MAINTENANCE

- **Cleaning:** For general cleaning, wipe the PU leather with a soft, damp cloth. For stubborn stains, use a mild leather cleaner. Avoid harsh chemicals or abrasive cleaners. The product care instructions recommend dry cleaning for specific components if necessary.
- **Inspection:** Periodically check all bolts and screws to ensure they are tight. Re-tighten if necessary to maintain stability and prevent squeaking.
- **Caster Care:** Keep the caster wheels free of hair and debris to ensure smooth movement.
- **Lubrication:** If the chair mechanisms become stiff or squeaky, a small amount of silicone-based lubricant can be applied to moving parts, avoiding contact with upholstery.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Chair squeaks when moving.	Loose bolts or lack of lubrication in moving parts.	Tighten all assembly bolts. Apply silicone lubricant to the tilt mechanism and gas lift if needed.
Chair does not adjust height.	Gas lift lever not engaged or gas lift cylinder malfunction.	Ensure the height adjustment lever is fully pulled. If the issue persists, contact customer service for a replacement gas lift.
Backrest does not recline or lock.	Recline lever not engaged or mechanism obstruction.	Ensure the recline lever is fully pulled. Check for any obstructions in the recline mechanism.
Armrests feel wobbly.	Loose screws connecting armrests.	Tighten the screws securing the armrests to the seat and backrest.
Massage function not working.	USB cable not connected or power source issue.	Ensure the USB cable is securely connected to a working USB power source. Try a different USB port or power adapter.

SPECIFICATIONS

Brand: Dowinx
Model Name: LS-6688
Color: Black
Product Dimensions (D x W x H): 33.07" x 22.44" x 8.66" (packaging dimensions)
Chair Dimensions (W x D x H): 20 inches W x 23 inches D x 55-58.5 inches H (overall)
Seat Height: 20.3 Inches (from floor)
Seat Depth: 23 inches
Chair Backrest Width: 34.2 Inches
Material: PU Leather, High-density Foam, Alloy Frame
Maximum Weight Recommendation: 350 Pounds
Reclining Position Count: 3 (90°, 135°, 165°)
Special Features: Adjustable Backrest, Adjustable Headrest, Arm Rest, Foot Rest, Head Support, Massage Lumbar Support
Item Weight: 50 pounds
Included Components: Arm Pad, Caster, Cushion

ENLARGED BACKREST AND SEAT

The most **oversized** gaming chairs compared with other products




Image: Technical drawing displaying various dimensions of the gaming chair, including height, width, and depth measurements.

WARRANTY AND CUSTOMER SUPPORT

Dowinx provides the following support for your gaming chair:

- **Replacement Service:** One-month replacement service for defective parts.
- **Repair Service:** One-year repair service for manufacturing defects.
- **Customer Service:** Our 24/7 customer service team is available to assist with any questions or concerns.

For assistance, please refer to the contact information provided in your product packaging or visit the official Dowinx website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DMW3KLH6>

More documents and user manuals: <https://manuals.plus/>