

[Manuals.plus](#) /

› [PARIS RHÔNE](#) /

› PARIS RHÔNE PE-MF010 4-in-1 Detachable Milk Frother and Steamer User Manual

PARIS RHÔNE PE-MF010

PARIS RHÔNE PE-MF010 4-in-1 Detachable Milk Frother and Steamer User Manual

Model: PE-MF010

1. INTRODUCTION

Thank you for choosing the PARIS RHÔNE PE-MF010 4-in-1 Detachable Milk Frother and Steamer. This appliance is designed to enhance your beverage experience by providing hot and cold milk foam, heated milk, and delicious hot chocolate. Please read this manual thoroughly before use to ensure safe and optimal operation.

2. PRODUCT FEATURES

- **Multifunctional 4-in-1:** Capable of heating milk to $60\pm5^{\circ}\text{C}/140\text{-}158^{\circ}\text{F}$, making hot chocolate, and frothing soft hot or cold foam for various beverages like coffee, latte macchiato, and cappuccino.
- **Large Capacity:** The carafe can produce up to 300ml (10.1oz) of hot milk or hot chocolate, or 150ml (5.1oz) of hot/cold milk froth, ideal for multiple servings. The angled spout design assists in creating latte art and minimizes spills.
- **Quick and Gentle Foam:** Enjoy frothy foam in approximately 2 minutes. The milk frother produces dense foam, enhancing both taste and presentation.
- **Hot Chocolate Function:** Features a unique chocolate lid design, allowing for hot chocolate preparation up to $85^{\circ}\text{C}/185^{\circ}\text{F}$.
- **Easy Cleaning & Safe Use:** The stainless steel milk jug is dishwasher safe for convenient cleaning. Equipped with Strix temperature control for automatic shut-off after preparation. Constructed with food-grade 304 stainless steel for safe and healthy use.

3. PACKAGE CONTENTS

Please check the package contents upon unboxing:

- Milk Frother Base
- Stainless Steel Milk Jug with Handle
- Transparent Lid
- Frothing Whisk (for frothing and heating)
- Stirring Whisk (for stirring and heating without foam)
- Chocolate Cover (for hot chocolate preparation)

4-in-1 Multifunctional

Meet your various taste needs



Image: All components of the PARIS RHÔNE PE-MF010 Milk Frother.

4. SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Initial Cleaning:** Before first use, wash the stainless steel milk jug, transparent lid, frothing whisk, stirring whisk, and chocolate cover with warm soapy water. Rinse thoroughly and dry. The main base unit should only be wiped with a damp cloth.
3. **Place the Base:** Position the frother base on a stable, flat, and dry surface. Ensure it is near a power outlet.
4. **Attach Whisk:** Select the appropriate whisk for your desired function (frothing or stirring). Place the whisk onto the magnetic pin at the bottom of the milk jug. Ensure it is securely seated.
5. **Place Jug on Base:** Place the milk jug onto the heating element base. Ensure it is properly aligned.

Your browser does not support the video tag.

Video: An overview of the PARIS RHÔNE Detachable 4-in-1 Milk Frother, demonstrating its components and initial setup.

5. OPERATING INSTRUCTIONS

The PARIS RHÔNE PE-MF010 offers four distinct functions, indicated by different LED lights on the base. Refer to the preparation guide below for specific settings.



Image: Visual representation of the 4-in-1 multifunctional capabilities.

5.1. Preparation Guide

Whisk	Icon	Function	Capacity	Time	Temperature
Stirring Whisk		Stirring & Heating (small amount of milk foam)	500ml / 16.9oz	< 430s	60-70°C / 140-158°F
Frothing Whisk		Frothing & Heating	250ml / 8.5oz	< 250s	60-70°C / 140-158°F
Frothing Whisk		Frothing Cold Foam	250ml / 8.5oz	120s	N/A
Chocolate Cover		Frothing & Heating Chocolate Milk (less milk foam)	500ml / 16.9oz	< 540s	70-80°C / 158-176°F

5.2. General Operation

1. **Fill Milk:** Pour milk into the jug, ensuring it does not exceed the MAX fill line for your chosen function (frothing or heating). The MAX line for frothing is lower than for heating to accommodate foam expansion.
2. **Close Lid:** Place the transparent lid securely on the jug.
3. **Select Function:** Press the power button once to turn on the unit. The indicator light will illuminate. Press the button repeatedly to cycle through the available functions until the desired setting is selected. The corresponding icon will light up.
4. **Start:** Once the desired function is selected, the frother will automatically begin operation.
5. **Completion:** The frother will automatically stop when the cycle is complete, and the indicator light may flash or change color.
6. **Serve:** Carefully remove the jug from the base and pour your prepared beverage. The jug may be hot, so handle with care.



Image: The milk frother showing its physical dimensions.



Image: Internal view of the milk jug indicating minimum and maximum fill levels for different functions.

6. MAINTENANCE

6.1. Cleaning

1. **Unplug:** Always unplug the frother from the power outlet before cleaning.
2. **Cool Down:** Allow the frother to cool completely before disassembling or cleaning.
3. **Milk Jug:** The stainless steel milk jug is dishwasher safe. For hand washing, use warm soapy water and a non-abrasive sponge. Rinse thoroughly.
4. **Whisks & Cover:** Remove the frothing whisk, stirring whisk, and chocolate cover. Wash them with warm soapy water and rinse thoroughly.
5. **Lid:** Wash the transparent lid with warm soapy water and rinse.
6. **Base Unit:** Wipe the exterior of the base unit with a soft, damp cloth. Do not immerse the base unit in water or any other liquid.
7. **Dry:** Ensure all parts are completely dry before reassembling or storing.

7. TROUBLESHOOTING

If you encounter any issues with your PARIS RHÔNE Milk Frother, please refer to the following common problems and solutions:

- **Frother does not turn on:** Ensure the power cord is securely plugged into a working outlet and the base unit. Check if the jug is correctly placed on the base.
- **Milk is not frothing or heating:** Verify that the correct whisk is installed for the desired function. Ensure the milk level is between the MIN and MAX lines for frothing. Use fresh, cold milk for best results.
- **Excessive foam or overflow:** Do not exceed the MAX fill line for frothing. Ensure the lid is properly secured during operation.
- **Unusual noise during operation:** Check that the whisk is correctly seated on the magnetic pin at the bottom of the jug. Ensure no foreign objects are inside the jug.
- **Burnt smell or residue:** Clean the interior of the jug thoroughly after each use to prevent milk residue buildup. Ensure the milk does not burn by not exceeding recommended fill levels or operating times.

If the problem persists, please contact customer support.

8. SPECIFICATIONS

Feature	Specification
Brand	PARIS RHÔNE
Model Name	PE-MF010
Special Feature	Non-stick, ergonomic
Color	Metallic Silver
Material	Stainless Steel
Recommended Uses	Residential
Product Care Instructions	Hand Wash Only (Jug is Dishwasher Safe)
Capacity	300 Milliliters (Frothing: 150ml, Heating: 300ml)
Style	Automatic Electric Milk Frother

Feature	Specification
Number of settings	4 (Hot Foam, Cold Foam, Hot Milk, Hot Chocolate)
Power Source	Corded Electric
Wattage	1000 watts
Item Weight	2.05 pounds
Package Dimensions	7.99 x 5.71 x 4.29 inches
UPC	719710546547

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact PARIS RHÔNE customer service. Refer to the contact details provided on the product packaging or the official PARIS RHÔNE website.

Website: [Visit the PARIS RHÔNE Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DQ55RMXQ>

More documents and user manuals: <https://manuals.plus/>