

Nood KCA423

Nood NEW Flasher 2.0 IPL Hair Removal Device & Shaving Starter Kit Instruction Manual

Model: KCA423 | Brand: Nood

1. INTRODUCTION

The Nood NEW Flasher 2.0 is an advanced Intense Pulsed Light (IPL) device designed for at-home hair removal. This kit also includes a premium 5-blade razor for preparing the skin before IPL treatments. The device aims to provide a convenient and effective solution for reducing unwanted hair growth on various body areas.

Key features include:

- **Powerful IPL Technology:** Targets hair at the root to slow regrowth.
- **Premium 5-Blade Razor Kit:** Refillable stainless steel razor for a close shave, reducing nicks and irritation.
- **Safe and Effective:** Designed for use on legs, underarms, bikini line, and other areas where hair grows.
- **Quick and Convenient:** Allows for efficient treatment of both large and small areas.
- **Sleek Design:** Gloss White finish for a modern aesthetic.

2. IMPORTANT SAFETY INFORMATION

Please read all safety instructions carefully before using the Nood Flasher 2.0. Failure to follow these instructions may result in injury or device malfunction.

- **Eye Protection:** Always wear appropriate eye protection (such as the provided glasses or sunglasses) during operation to protect your eyes from the intense light pulses.
- **Skin Tone and Hair Color Compatibility:** IPL technology works by targeting melanin in the hair follicle. It is most effective on lighter skin tones with darker hair.
- **Not Recommended For:**
 - Darker skin tones (brown, dark-brown, black)
 - Light blonde, red, or grey hair

IPL requires a contrast between the melanin in your hair and the melanin in your skin. A skin safety test is required before treatment; instructions are included in the full manual.

- **External Use Only:** This device is intended for external use on the skin surface only.
- **Skin Preparation:** Ensure the skin is clean, dry, and freshly shaved before each treatment. Do not wax,

pluck, or use depilatory creams.

- **Avoid Sun Exposure:** Avoid direct sun exposure or tanning beds for at least two weeks before and after treatment. Use sunscreen on treated areas.
- **Consult a Doctor:** If you have any underlying skin conditions, medical implants, or are pregnant/breastfeeding, consult a healthcare professional before use.



REAL CUSTOMERS, REAL RESULTS

trusted by over
750,000 noodists

"I love it! It's painless, quick, and very easy to use. I was hesitant because laser treatments have been hit or miss for me, but this worked absolutely great. Highly recommend"


KV

Figure 2.1: IPL Skin Tone and Hair Color Compatibility Chart. This chart illustrates which skin tones and hair colors are suitable for IPL treatment. IPL is most effective on lighter skin with darker hair, requiring a contrast in melanin.

3. WHAT'S INCLUDED

Your Nood NEW Flasher 2.0 + Shaving Starter Kit includes the following components:

- Nood Flasher 2.0 IPL Device
- Power Adapter
- Premium 5-Blade Razor
- Safety Glasses (for eye protection during IPL treatment)
- User Manual (this document)



long-lasting hair removal in just 4 weeks

WORKS ON:

- ✓ LEGS
- ✓ CHEST
- ✓ ARMS
- ✓ UNDERARMS
- ✓ FACE
- ✓ NETHER REGIONS
- ✓ BACK
- ✓ BOOTY

Figure 3.1: The Nood Flasher 2.0 IPL device shown with its power adapter and other accessories included in the kit.

4. SETUP

- 1. Prepare the Skin:** Ensure the area to be treated is clean, dry, and freshly shaved. Do not wax or pluck, as IPL requires the hair follicle to be present.
- 2. Connect Power:** Plug the power adapter into the Nood Flasher 2.0 device and then into a power outlet. The device requires continuous power during operation.
- 3. Wear Eye Protection:** Put on the provided safety glasses to protect your eyes from the intense light.
- 4. Power On:** Press and hold the power button (usually located on the side or front) for a few seconds until the device powers on and the fan starts.
- 5. Select Intensity Level:** The device typically starts at Level 1. Use the control buttons to adjust the intensity level according to your comfort and skin sensitivity. It is recommended to start with a lower level and gradually increase it. The device supports up to 7 intensity levels.

quicker, clinically proven results

THE FLASHER 2.0™

precisionpulse™ IPL technology destroys hair follicles

THE NOOD RAZOR

premium stainless steel + 360° moisture strip to prep skin for IPL treatment



Figure 4.1: The Nood Flasher 2.0 IPL device with its display showing the selected intensity level and remaining flashes. The device is connected to its power adapter.

5. OPERATING INSTRUCTIONS

- 1. Position the Device:** Place the treatment window of the Nood Flasher 2.0 firmly and completely against the skin at a 90-degree angle. The device will not flash unless it detects full skin contact.
- 2. Initiate Flash:**
 - **Manual Mode:** Press the main flash button for a single pulse.
 - **Auto Mode:** Press and hold the circular button to activate auto mode. The device will automatically emit continuous flashes as you glide it across the skin.
- 3. Treatment Technique:** Glide the device slowly and evenly over the treated area, ensuring each pulse overlaps slightly with the previous one to avoid missed spots.
- 4. Treatment Schedule:** For optimal results, use the device twice a week for the first 4-8 weeks. After this initial phase, reduce frequency to once a month or as needed for maintenance.
- 5. Expected Results:** Visible hair reduction can be observed after the first few uses. Significant reduction (up to 90%) is typically seen after 4+ weeks of consistent use. Individual results may vary based on hair type, color, and coarseness.
- 6. Post-Treatment Care:** After treatment, you may apply a soothing lotion or aloe vera gel to the treated area if

desired. Avoid direct sun exposure.

7. **Power Off:** After completing your session, press and hold the power button until the device turns off and the fan stops.




Figure 5.1: Illustration of the Nood Flasher 2.0 being used for quick 10-minute treatments on various body parts, highlighting its efficiency for different areas.

Your browser does not support the video tag.

Video 5.1: Official Nood Beauty video demonstrating the Flasher 2.0 for permanent hair removal, highlighting results in 8 weeks. This video provides a visual guide on how to use the device effectively.

6. MAINTENANCE

- **Cleaning:** After each use, ensure the device is powered off and unplugged. Gently wipe the treatment window and the device surface with a soft, dry cloth. Do not use abrasive cleaners or immerse the device in water.
- **Storage:** Store the Nood Flasher 2.0 in a cool, dry place, away from direct sunlight and out of reach of children.

7. TROUBLESHOOTING

If you encounter any issues with your Nood Flasher 2.0, please refer to the following common troubleshooting tips:

- **Device Not Powering On:** Ensure the power adapter is securely connected to both the device and a working power outlet. Press and hold the power button for a few seconds.
- **Device Not Flashing:** The device requires full contact with the skin to emit a flash. Ensure the treatment window is pressed firmly and completely against the skin. Also, check that the intensity level is set.
- **Skin Irritation:** If you experience redness or discomfort, reduce the intensity level or discontinue use. Ensure you are following all skin preparation and post-treatment care instructions.
- **No Visible Results:** Consistent use according to the recommended schedule is crucial. Ensure your skin tone and hair color are compatible with IPL technology. Results vary by individual.

For further assistance, please contact Nood Beauty customer support.

8. SPECIFICATIONS

Feature	Detail
Model Number	KCA423

Feature	Detail
Brand	Nood
UPC	850071754018
Technology	IPL (Intense Pulsed Light)
Intensity Levels	7
Special Features	Durable, Ergonomic, Portable, Reusable
Included Razor Blades	5
Power Input	AC 100-240V, 50/60Hz, 1.5A
Output	12V, 3.0A (36.0W)
Manufacturer	Nood

9. WARRANTY AND SUPPORT

For warranty information, product support, or any questions regarding your Nood NEW Flasher 2.0 + Shaving Starter Kit, please contact Nood Beauty directly. Refer to the product packaging or the official Nood Beauty website for the most up-to-date contact details and warranty terms.

You can visit the [Nood Store on Amazon](#) for more information.