



[Manuals.plus](#) /

› [SUNVIVIPRO](#) /

› SUNVIVIPRO Paraffin Wax Warmer Kit User Manual

SUNVIVIPRO B0DYF5NFDT

SUNVIVIPRO Paraffin Wax Warmer Kit User Manual

Model: B0DYF5NFDT

1. INTRODUCTION

Thank you for choosing the SUNVIVIPRO Paraffin Wax Warmer Kit. This professional-grade, large-capacity 4000ml paraffin wax heater is designed for moisturizing hands and feet, offering a spa-like experience at home. It features intelligent temperature control with auto-time and keep-warm functions for safe and effective use. Please read this manual thoroughly before operation to ensure proper use and maintenance.



Image 1.1: The SUNVIVIPRO Paraffin Wax Warmer Kit, including the warmer unit, paraffin wax blocks, plastic gloves, thermal mitts, silicone scraper, and brush.

2. SAFETY INFORMATION

This product is intended for personal care use. Always follow these safety guidelines:

- Do not immerse the unit in water or any other liquid.
- Keep out of reach of children and pets.
- Always test the wax temperature on a small area of your skin before full application to avoid burns.
- Do not use on broken, irritated, or sensitive skin. Consult a physician if you have any skin conditions or circulatory problems.
- Unplug the unit when not in use and before cleaning.
- Ensure the unit is placed on a stable, heat-resistant surface.
- Do not leave the unit unattended while operating.

3. PRODUCT COMPONENTS

Your SUNVIVIPRO Paraffin Wax Warmer Kit includes the following items:

- 1x 4000ml Paraffin Wax Warmer Unit
- 8x Paraffin Wax Blocks
- 50x Plastic Gloves Liners
- 2x Thermal Mitts for Hands
- 2x Thermal Mitts for Feet
- 1x Silicone Scraper
- 1x Brush
- 1x Heat Insulating Grid



Image 3.1: Detailed view of all included accessories and the main warmer unit.

4. SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Placement:** Place the paraffin wax warmer on a flat, stable, and heat-resistant surface. Ensure it is away from water sources and flammable materials.
3. **Insert Grid:** Place the heat insulating grid at the bottom of the wax warmer's inner pot.
4. **Add Wax:** Open the paraffin wax blocks and place them into the warmer. The 4000ml capacity allows for ample wax for full-body treatments.
5. **Connect Power:** Plug the power cord into a suitable electrical outlet.

5. OPERATING INSTRUCTIONS

5.1. Wax Melting and Temperature Control

The unit features an intelligent temperature control system for efficient and safe operation.

1. **Power On:** Press the power button to turn on the warmer. The digital display will illuminate.
2. **Set Temperature:** Use the '+' and '-' buttons to adjust the desired temperature. The temperature range is 113°F to 167°F (45°C to 75°C). For quick melting, set to 167°F.

3. **Melting Time:** The wax will typically melt in about 20 minutes when set to 167°F (for 4 lbs of wax).
4. **Automatic Cooling & Keep Warm:** Once the wax reaches the set temperature, the unit will automatically cool to a comfortable 131°F (55°C) and maintain this temperature for consistent, long-lasting care.

Fast or Slow, Up To You

Professional Temperature Control System



Digital Display



Fast Heating



Adjustable Temperature



Smooth Care

Desired Temperature Display

Real-Time Temperature Display

Heat Up

Power Switch

Cooling

Set to Switch 2 Modes



Image 5.1: The warmer's control panel with digital display for temperature and mode settings.

20 Minutes Fast Wax Heating

4 lbs wax melt at 167°F



Image 5.2: Visual representation of the 20-minute fast wax heating process.

5.2. Application Process

Follow these steps for a rejuvenating wax treatment:

1. **Prepare Skin:** Ensure the area to be treated (hands, feet, elbows, knees) is clean and dry.
2. **Test Temperature:** Before dipping, test a small amount of wax on your wrist to ensure it is a comfortable temperature.
3. **Dip:** Slowly dip the desired body part into the melted wax. Remove it, allow the wax to solidify slightly, and repeat 3-5 times to build up a thick layer.
4. **Cover:** Immediately after dipping, cover the waxed area with a plastic glove liner (for hands/feet) and then with the thermal mitts to retain heat.
5. **Relax:** Allow the wax to work for 5-10 minutes.
6. **Remove:** Gently peel off the wax. The wax should come off easily, taking dead skin cells with it.

7. **Post-Care:** Dispose of the used wax. No need to rinse the skin; simply massage any remaining moisture into the skin.




Image 5.3: Visual guide to the easy-to-use application process.



Image 5.4: Demonstrating the easy peel-off nature of the wax.

5.3. Benefits and Applications

The paraffin wax treatment offers numerous benefits:

- **Moisturizing:** Revives rough, dry, and damaged skin, leaving it soft and hydrated.
- **Pain Relief:** Aids in relieving joint pain, arthritis, and muscle stiffness. The heat promotes blood circulation.
- **Relaxation:** Helps relax muscles, reduce fatigue, and relieve stress.
- **Improved Circulation:** Stimulates blood flow for better circulation.

Enjoy Your Home Paraffin Bath Spa



Heat Therapy- Relieves sore joints and muscles




Skin Moisturizer- No more cracked or dry skin



Promotes Sleep



Relaxation & Fatigue Relief



Pet Care

Image 5.5: Overview of the wellness benefits of paraffin wax therapy.

Indulge in a hydrating and rejuvenating wax therapy.

Revives rough, dry, and damaged skin. Perfect for both spa professionals and home care.

Hands



Heels



Feet



Elbows



Image 5.6: Examples of body areas suitable for paraffin wax treatment.

5.4. Pet Care Application

Paraffin bath can also be beneficial for pets, especially older ones or those with dry paw pads.

- **Paw Protection:** Helps soothe dry or cracked paw pads.
- **Joint Pain Relief:** Can ease arthritis discomfort in older pets.
- **Fur Care:** Warm wax can help soften and untangle matted fur (use with caution and professional guidance).

Note: Always consult with a veterinarian before using on pets, and ensure the wax temperature is very mild and safe for animal skin.

Pet Wellness




Paw Protection

Paraffin treatment soothes dog paws.

Fur Care

Warm wax softens and untangles pet fur.



Senior Support

Paraffin eases arthritis and keeps aging pets comfortable.

Image 5.7: Benefits of paraffin wax for pet wellness.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and hygiene of your paraffin wax warmer.

1. **Power Off and Unplug:** Always turn off and unplug the unit before cleaning. Allow it to cool completely.
2. **Remove Hardened Wax:** Once the wax has hardened, use the provided silicone scraper or a plastic utensil to gently scrape out the solidified wax from the inner pot.
3. **Reheat for Residue:** If there is stubborn residue, you may briefly reheat the unit to slightly soften the wax, then scrape it away. Do not use sharp objects that could damage the non-stick surface.
4. **Wipe Clean:** Use a soft, damp cloth or paper towel to wipe the interior and exterior of the warmer. For stubborn spots, a small amount of rubbing alcohol can be used on the non-stick surface.
5. **Dry Thoroughly:** Ensure the unit is completely dry before storing or next use.



Image 6.1: Easy cleaning steps for the wax warmer.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Wax not melting or heating slowly.	Incorrect temperature setting; insufficient power; too much wax.	Ensure temperature is set to 167°F for fast melting. Check power connection. Reduce wax quantity if overloaded.
Wax is too hot or too cold for application.	Temperature not stabilized; incorrect setting.	Allow unit to reach and stabilize at 131°F (keep warm setting). Always test wax on wrist before full application.
Wax does not peel off easily.	Wax layer too thin; not enough cooling time.	Dip 3-5 times to build a thicker layer. Ensure sufficient cooling time (5-10 minutes) before peeling.
Unit not turning on.	No power; faulty outlet; unit malfunction.	Check power cord connection. Try a different outlet. If problem persists, contact customer support.

8. SPECIFICATIONS

- **Model:** B0DYF5NFD T
- **Brand:** SUNVIVIPRO
- **Capacity:** 4000ml

- **Temperature Range:** 113°F - 167°F (45°C - 75°C)
- **Keep Warm Temperature:** 131°F (55°C)
- **Fast Heating Time:** Approx. 20 minutes (for 4 lbs wax at 167°F)
- **Package Dimensions:** 15.16 x 9.33 x 7.91 inches
- **Weight:** 7.89 Pounds
- **Manufacturer:** Sunvivipro
- **Country of Origin:** China
- **UPC/GTIN:** 810173792868

Product size



Image 8.1: Product dimensions for the paraffin wax warmer.

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the contact details provided with your product packaging or visit the official SUNVIVIPRO website. SUNVIVIPRO is committed to providing comprehensive warranties and attentive

after-sales service to ensure your peace of mind.

