

Manuals.plus /
› KAYOTOM /
› KAYOTOM K9 Super Mini Walkie Talkie Instruction Manual

KAYOTOM K9

KAYOTOM K9 Super Mini Walkie Talkie Instruction Manual

Model: K9 | Brand: KAYOTOM

1. INTRODUCTION

Thank you for choosing the KAYOTOM K9 Super Mini Walkie Talkie. This manual provides essential information for the safe and efficient operation of your two-way radio. Please read it thoroughly before use and retain it for future reference.

The KAYOTOM K9 is a compact and lightweight two-way radio designed for clear and reliable communication in various environments, including restaurants, hotels, supermarkets, and outdoor activities. Its features include a comfortable earpiece, noise reduction technology, and Type-C charging.

2. PRODUCT OVERVIEW

2.1 Package Contents

- KAYOTOM K9 Walkie Talkie Unit (2x)
- Earpiece with Microphone (2x)
- USB Type-C Charging Cable (2x)
- User Manual

2.2 Component Identification

Familiarize yourself with the main components of your walkie talkie:

Product key analysis



Figure 1: KAYOTOM K9 Walkie Talkie Component Diagram. This image illustrates the location of the On/Off key, PTT1 and PTT2 keys, Volume +/-, and Type-C charging port.

- **PTT Button (Push-to-Talk):** Used to transmit your voice.
- **On/Off Key:** Powers the device on or off.
- **Volume Up/Down Keys:** Adjusts the listening volume.
- **Type-C Charging Port:** For connecting the charging cable.
- **Earpiece Port:** For connecting the included earpiece.
- **Clip:** For attaching the walkie talkie to clothing.

3. SETUP

3.1 Initial Charging

Before first use, fully charge your walkie talkie.

1. Connect the USB Type-C charging cable to the charging port on the walkie talkie.
2. Plug the other end of the cable into a compatible USB power adapter (not included) or a computer USB port.
3. The indicator light will show charging status (e.g., red for charging, green for fully charged).
4. A full charge typically takes approximately 2.5 hours.

The walkie talkie offers up to 12 hours of continuous use and 48 hours of standby time on a full charge.

3.2 Attaching the Earpiece

The included G-shape earpiece provides comfortable and private communication.

1. Insert the earpiece plug firmly into the earpiece port on the walkie talkie.
2. Place the G-shape ear hook over your ear. The earpiece is designed to rotate 360 degrees to fit either the left or right ear comfortably.
3. Adjust the earpiece for a secure and comfortable fit. The PTT button on the earpiece cable allows for convenient communication.




Figure 2: Comfortable Earpiece Design. The G-shape ear hook and 360-degree rotating headset ensure comfortable wearing for extended periods.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

- To power on: Press and hold the **On/Off Key** until you hear an audible prompt.
- To power off: Press and hold the **On/Off Key** until you hear an audible prompt indicating power off.

4.2 Adjusting Volume

Use the **Volume Up (+)** and **Volume Down (-)** keys on the side of the walkie talkie to adjust the listening volume to a comfortable level.

4.3 Selecting Channels

The KAYOTOM K9 supports 16 channels. To communicate with another walkie talkie, both devices must be set to the same channel.



Figure 3: Channel Selection. The walkie talkies offer 16 channels for communication.

Channel selection is typically done via a dedicated button or a combination of buttons. Refer to the specific instructions provided with your device for channel changing procedures. Ensure all units intended for communication are on the same channel.

4.4 Transmitting and Receiving

1. To **transmit** (speak): Press and hold the **PTT button** (either on the walkie talkie unit or on the earpiece cable). Speak clearly into the microphone (located on the earpiece cable or the walkie talkie unit itself). Release the PTT button when you finish speaking.
2. To **receive** (listen): Ensure the PTT button is not pressed. The walkie talkie will automatically receive transmissions on the selected channel.

For optimal clarity, hold the microphone approximately 2-5 cm (1-2 inches) from your mouth when speaking.

5. MAINTENANCE

- **Cleaning:** Wipe the walkie talkie with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.
- **Water Resistance:** This device is **not water resistant**. Avoid exposure to rain, splashes, or immersion in water.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Battery is depleted.	Charge the walkie talkie using the Type-C cable.
Cannot communicate with other units	Units are on different channels.	Ensure all units are set to the same channel.
Poor audio quality / Static	Out of range; Obstructions; Low battery.	Move closer to the other unit; Move to an open area; Charge the battery.
Earpiece not working	Earpiece not fully plugged in; Faulty earpiece.	Ensure earpiece is securely connected; Try another earpiece if available.

7. SPECIFICATIONS

Feature	Specification
Model	K9
Dimensions (L x W x H)	2" x 0.98" x 0.59" (approx. 5.08cm x 2.49cm x 1.5cm)
Weight	Approx. 0.7 oz (20g)
Number of Channels	16
Frequency Range	400-520MHz
Talking Range (Open Area)	Up to 1000 meters (approx. 3280 feet)

50000 SQ FT

INDOOR INTERCOM DISTANCE

48 HOUR
STAND-BY TIME

12
HOUR
CONTINUOUS USE FOR 12 HOURS

TYPE-C CHARGING PORT



Figure 5: Charging and Battery Life. The device features a Type-C charging port, offering up to 48 hours standby and 12 hours continuous use.

8. WARRANTY AND SUPPORT

8.1 Warranty Information

The KAYOTOM K9 Super Mini Walkie Talkie comes with a **1-year limited warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or exposure to water.

Please retain your proof of purchase for warranty claims.

8.2 Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact KAYOTOM customer support through the retailer where you purchased the product or visit the official KAYOTOM website for contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F9K4TDBL>

More documents and user manuals: <https://manuals.plus/>