

IFOLAINA 150Z

IFOLAINA Crystal LED Light Base Instruction Manual

Brand: IFOLAINA | Model: 150Z

1. PRODUCT OVERVIEW

The IFOLAINA Crystal LED Light Base is designed to enhance the visual appeal of various transparent or translucent objects such as crystal art, glass figurines, acrylic displays, and 3D crystal statues. This round light base provides dynamic and static illumination options to highlight your cherished items.



Figure 1: The IFOLAINA Crystal LED Light Base, a clear, round pedestal with internal LED lights.

Key Features:

- **High-Quality Material:** Constructed from durable K9 Crystal for clarity and aesthetic appeal.
- **Compact Design:** Round shape with a diameter of approximately 3 inches (7.62 cm).
- **Non-Rotating:** The top surface is flat and stationary, ideal for stable display.
- **Multiple Lighting Modes:** Features 7 distinct lighting modes, including color-changing and static options.
- **Easy Operation:** Equipped with a simple switch for convenient control.
- **USB Powered:** Operates via an included USB cable, offering flexible power options.

2. SETUP INSTRUCTIONS

Setting up your IFOLAINA Crystal LED Light Base is a straightforward process.

1. **Unpack:** Carefully remove the light base and USB cable from its packaging.
2. **Connect Power:** Insert the small end of the provided USB cable into the power input port on the side of the light base.
3. **Power Source:** Connect the standard USB end of the cable to a compatible USB power source, such as a USB wall adapter (not included), a computer USB port, or a power bank.
4. **Placement:** Place the light base on a stable, flat surface.
5. **Display Item:** Carefully place your crystal, glass, or acrylic display item on the flat top surface of the light base.




Figure 2: Illustration showing the USB power input and the location of the color modes switch on the light base.

3. OPERATING INSTRUCTIONS

The IFOLAINA Crystal LED Light Base features a simple control mechanism to cycle through its various lighting modes.

Controlling Lighting Modes:

Locate the small button or switch on the side of the light base. Each press of this button will cycle through the available lighting modes in the following sequence:

1. **Colors Slow Flashing:** Lights transition smoothly between colors.
2. **Colors Quick Flashing:** Lights change colors rapidly.
3. **Constant Yellow:** Steady yellow illumination.
4. **Constant White:** Steady white illumination.
5. **Constant Blue:** Steady blue illumination.
6. **Constant Green:** Steady green illumination.
7. **Constant Red:** Steady red illumination.
8. **Off:** The light base will turn off after cycling through all modes. Press again to restart the sequence.




Figure 3: Visual representation of the 7 available lighting modes and how to cycle through them.



Figure 4: The light base effectively illuminating a 3D crystal statue, demonstrating its multi-functional use.

4. MAINTENANCE

To ensure the longevity and optimal performance of your IFOLAINA Crystal LED Light Base, follow these simple maintenance guidelines:

- **Cleaning:** Use a soft, dry, lint-free cloth to gently wipe the surface of the light base. For stubborn smudges, slightly dampen the cloth with water and then dry immediately. Avoid abrasive cleaners or solvents, as they may damage the crystal finish.
- **Storage:** When not in use for extended periods, disconnect the USB cable and store the light base in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Handle the light base with care to prevent scratches or damage to the crystal.

5. TROUBLESHOOTING

If you encounter any issues with your IFOLAINA Crystal LED Light Base, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light base does not turn on.	No power supply or loose connection.	Ensure the USB cable is securely connected to both the light base and the power source. Try a different USB port or power adapter.
Lights are dim or flickering.	Insufficient power or faulty cable.	Use a power source that provides adequate power (e.g., a wall adapter instead of a low-power USB port). Try a different USB cable if available.
Cannot change lighting modes.	Switch malfunction or unit unresponsive.	Ensure the unit is powered on. Press the switch firmly. If the issue persists, contact customer support.

6. SPECIFICATIONS

Detailed specifications for the IFOLAINA Crystal LED Light Base (Model: 150Z).

Feature	Detail
Model Number	150Z
Material	K9 Crystal
Shape	Round
Diameter	Approx. 3 inches (7.62 cm)
Height	Approx. 1.57 inches (3.99 cm)
Item Weight	10.2 ounces (289.2 grams)
Power Source	USB Cable (included)
Lighting Modes	7 (Colors Slow Flashing, Colors Quick Flashing, Constant White, Constant Yellow, Constant Blue, Constant Green, Constant Red)
Rotation	No




Figure 5: Detailed dimensions of the IFOLAINA Crystal LED Light Base.

7. WARRANTY AND SUPPORT

For any questions, concerns, or technical assistance regarding your IFOLAINA Crystal LED Light Base, please contact the manufacturer or seller directly. Refer to your purchase documentation for specific warranty details and contact information.

Manufacturer: Philosophers Arts and Crafts

Return Policy: This product typically comes with a 30-day return/replacement policy. Please check your specific purchase terms for details.

© 2024 IFOLAINA. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question