

[Manuals.plus](#) /

> [OLIXIS](#) /

> OLIXIS C-6002-BN-EUG-2 Home Office Desk Chair Instruction Manual

OLIXIS C-6002-BN-EUG-2

OLIXIS C-6002-BN-EUG-2 Home Office Desk Chair Instruction Manual

Model: C-6002-BN-EUG-2

1. INTRODUCTION

Thank you for choosing the OLIXIS Home Office Desk Chair. This manual provides detailed instructions for the assembly, operation, and maintenance of your new chair. Please read this manual thoroughly before assembly and retain it for future reference to ensure safe and efficient use of the product.





Figure 1: Front view of the OLIXIS Home Office Desk Chair.

2. SAFETY INFORMATION

- Always follow the assembly instructions provided.
- Do not exceed the maximum weight recommendation of 300 pounds (136 kg).
- Keep the chair away from heat sources and sharp objects to prevent damage to the upholstery.
- Ensure all screws and bolts are tightened securely before use. Periodically check and re-tighten as necessary.
- Avoid standing on the chair or using it as a step stool.
- Do not allow children to play on or around the chair unsupervised.
- In case of any doubt, consult this user manual or contact customer support.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Backrest (A) x1
- Seat Cushion (B) x1
- Footrest (C) x1
- Mechanism (D) x1

- Backrest Support Bracket (E) x1
- Gas Lift (F) x1
- Base (G) x1
- Casters (H) x5
- Lumbar Pillow (I) x1
- Armrests (O) x2
- Footrest Support Bars (P) x2
- Assembly Hardware (screws, Allen wrench)



Video 1: Unboxing and component display. This video demonstrates all parts included in the package.

4. SETUP AND ASSEMBLY

Follow these steps to assemble your OLIXIS Home Office Desk Chair. It is recommended to assemble the chair on a soft, clean surface to prevent damage.

Step 1: Attach Casters to the Base

1. Insert the five casters (H) into the holes at the end of each leg of the chair base (G). Push firmly until they click into place.

Step 2: Install Gas Lift

2. Place the gas lift (F) into the center hole of the assembled base (G).

Step 3: Attach Armrests to Seat Cushion

3. Align the armrests (O) with the pre-drilled holes on the underside of the seat cushion (B). Ensure the armrests are oriented correctly (left and right).
4. Secure the armrests using the provided screws and Allen wrench. Do not overtighten.

Step 4: Attach Footrest to Seat Cushion

4. Attach the footrest support bars (P) to the underside of the seat cushion (B) using the provided screws.
5. Slide the footrest (C) onto the support bars.

Step 5: Install Mechanism to Seat Cushion

5. Align the mechanism (D) with the pre-drilled holes on the underside of the seat cushion (B). Ensure the front of the mechanism faces the front of the seat.
6. Secure the mechanism using the provided screws and Allen wrench.

Step 6: Attach Backrest to Seat Cushion

6. Attach the backrest support bracket (E) to the backrest (A) using the provided screws.
7. Align the backrest support bracket (E) with the corresponding holes on the mechanism (D) and secure with screws.

Step 7: Connect Seat Assembly to Gas Lift

7. Carefully place the assembled seat and backrest onto the gas lift (F), ensuring the gas lift cylinder is properly inserted into the mechanism.

Step 8: Attach Lumbar Pillow

8. Attach the detachable lumbar pillow (I) to the backrest using its integrated straps. Adjust to your preferred height.



Video 2: Full assembly guide. This video provides a visual walkthrough of the entire chair assembly.

5. OPERATING INSTRUCTIONS

Your OLIXIS Home Office Desk Chair offers multiple adjustment features for personalized comfort.

5.1. Height Adjustment

- To raise the seat height: While seated, pull the right lever (under the seat) upwards and lift your body slightly. Release the lever at the desired height.
- To lower the seat height: While seated, pull the right lever upwards and apply pressure to the seat. Release the lever at the desired height.

5.2. Reclining Function

- To recline the backrest: Pull the left lever (under the seat) outwards to unlock the recline mechanism. Lean back to your desired angle (up to 135°). Push the lever inwards to lock the backrest in position.
- To adjust rocking tension: Rotate the round knob under the seat to increase or decrease the tension for rocking.

5.3. Footrest Operation

- To extend the footrest: Pull the footrest (C) outwards from under the seat.
- To retract the footrest: Push the footrest (C) back under the seat until it is fully stored.

5.4. Lumbar Pillow Adjustment

- The lumbar pillow (I) is detachable and can be adjusted vertically along the backrest using its straps to provide support where needed.



Detachable Lumbar Support



Thickened Seat



Retractable Footrest



Sturdy metal base

Figure 2: Overview of adjustable features.

90°-135°

Reclining Office Chice

Easily switch between life modes




Figure 3: Ergonomic support points and reclining posture.

Working ►



Resting ►



◀ Gaming



Figure 4: Chair in working, gaming, and resting positions.

6. MAINTENANCE

Proper maintenance will extend the life and appearance of your chair.

- **Cleaning:** The PU leather upholstery and detachable pillow can be cleaned with a soft, damp cloth. For tougher stains, use a mild soap solution and wipe dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Hardware:** Periodically check all screws and bolts to ensure they are tight. Re-tighten as needed to maintain stability and safety.
- **Casters:** Keep the casters free of hair and debris to ensure smooth movement.
- **General Care:** Avoid prolonged exposure to direct sunlight to prevent fading and material degradation.



Figure 5: Material details, showing breathable and easy-to-clean surfaces.

7. TROUBLESHOOTING

If you encounter any issues with your chair, refer to the following common problems and solutions:

- **Chair is wobbly:** Ensure all assembly screws are securely tightened. Check that the gas lift is properly seated in the base and mechanism.
- **Height adjustment not working:** Verify that the gas lift lever is functioning correctly and not obstructed. Ensure the gas lift is fully inserted into the mechanism and base.
- **Casters not rolling smoothly:** Check casters for any trapped debris, hair, or dust. Clean as necessary. Ensure casters are fully inserted into the base.
- **Recline mechanism stuck:** Ensure the recline lock lever is fully disengaged. Check for any obstructions under the seat mechanism.

For persistent issues or problems not listed here, please contact customer support.

8. SPECIFICATIONS

Feature	Specification
Brand	OLIXIS
Model Number	C-6002-BN-EUG-2
Color	Pu-brown
Material	Faux Leather, Sponge (Fill Material), Metal (Frame)
Product Dimensions (D x W x H)	31.5"D x 27.6"W x 45.7"H (80cm x 70cm x 116cm)
Item Weight	58.2 Pounds (26.4 kg)
Maximum Weight Recommendation	300 Pounds (136 kg)
Adjustable Features	Adjustable Backrest (up to 135°), Adjustable Height, Foot Rest, Rolling, Upholstered Leather
Back Style	Continuous Back
Arm Style	Fixed armrest
Leg Style	Wheels (Mute PU casters)
Certifications	SGS certified Class 3 gas cylinder, BIFIMA certified metal base



Solid Base

300LBS Load Capacity Safe And Durable



Figure 6: Solid base with 300 lbs load capacity.




Figure 7: Gas cylinder for smooth height adjustment.



Figure 8: Mute PU casters for smooth movement.

9. WARRANTY AND SUPPORT

Your OLIXIS Home Office Desk Chair is covered by a manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions.

For technical assistance, missing parts, or warranty claims, please contact OLIXIS customer support through the retailer where the product was purchased or visit the official OLIXIS website for contact information.

When contacting support, please have your model number (C-6002-BN-EUG-2) and proof of purchase readily available.

© 2026 OLIXIS. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0GS5KC6Y4>

More documents and user manuals: **<https://manuals.plus/>**