

[Manuals.plus](#) /

› [Sorandy](#) /

› Sorandy Professional Mechanical Watch Demagnetizer User Manual

Sorandy Sorandydfpne6kbx4

Sorandy Professional Mechanical Watch Demagnetizer User Manual

Model: Sorandydfpne6kbx4

INTRODUCTION

The Sorandy Professional Mechanical Watch Demagnetizer is designed to remove magnetism from mechanical watches, which can affect their accuracy. This compact and lightweight device is an essential tool for watch enthusiasts and professionals to maintain optimal performance of mechanical timepieces.



Sturdy and durable, this demagnetizer has a long service time

Used for demagnetizing your mechanical watches

Image: The Sorandy Professional Mechanical Watch Demagnetizer shown alongside a mechanical watch, highlighting its application in maintaining watch accuracy.

SAFETY INFORMATION

- Keep the device away from strong magnetic fields when not in use to prevent interference.
- Do not disassemble the device. Refer to qualified personnel for repairs.
- Ensure proper battery installation to avoid damage.
- Keep out of reach of children.
- Avoid exposing the device to water or excessive moisture.

PACKAGE CONTENTS

- 1 x Sorandy Professional Mechanical Watch Demagnetizer
- *Note: 2 x AA batteries are required and not included.*

SETUP

1. **Open the Battery Compartment:** Locate the battery compartment on the underside of the demagnetizer. Gently slide or lift the cover to open it.
2. **Insert Batteries:** Insert two (2) AA batteries into the compartment, ensuring correct polarity (+ and -) as indicated inside the compartment.
3. **Close the Compartment:** Replace the battery compartment cover securely.



Image: View of the demagnetizer with its battery compartment open, illustrating where to insert the AA batteries.

OPERATING INSTRUCTIONS

Follow these steps to demagnetize your mechanical watch:

1. **Power On:** Ensure batteries are installed. Press the red button or switch located on the device to turn it on. A small indicator light may illuminate.

2. **Position the Watch:** Place your mechanical watch directly onto the designated demagnetization area of the device. This is typically the flat surface under the clear cover.
3. **Activate Demagnetization:** While the watch is on the device, press and hold the power button or switch for approximately 5-10 seconds. You may hear a faint hum.
4. **Slowly Lift:** While still holding the button, slowly lift the watch away from the demagnetizer to a distance of about 10-15 cm (4-6 inches) before releasing the button. This gradual removal helps to ensure complete demagnetization.
5. **Power Off:** Release the button and turn off the device after use to conserve battery life.
6. **Verify:** Check your watch's accuracy. If magnetism persists, repeat the process.



Image: The demagnetizer with its protective cover open, showing the area where a watch should be placed for demagnetization.

MAINTENANCE

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the demagnetizer in a cool, dry place, away from direct sunlight and strong magnetic fields.
- **Battery Replacement:** If the indicator light dims or the device performs weakly, replace the AA batteries. Remove batteries if storing for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	No batteries, incorrect battery polarity, or dead batteries.	Check battery installation, ensure correct polarity, or replace with new AA batteries.
Watch remains magnetized.	Improper demagnetization technique or very strong magnetism.	Repeat the operating steps carefully, ensuring slow lifting. For very strong magnetism, multiple attempts may be needed.
Indicator light is dim.	Low battery power.	Replace batteries with new AA batteries.

SPECIFICATIONS

- **Model:** Sorandydfpne6kbx4
- **Material:** Plastic
- **Power Source:** 2 x AA Batteries (not included)
- **Dimensions:** Approximately 9.5 x 5.2 x 3.5 cm (3.7 x 2.0 x 1.4 inches)
- **Weight:** Approximately 77g (2.7 oz)
- **Manufacturer:** Sorandy
- **Country of Origin:** China

WARRANTY AND SUPPORT

This product comes with a limited warranty. For specific warranty details or technical support, please refer to the retailer or manufacturer's official website. Keep your purchase receipt for warranty claims.

Manufacturer: Sorandy

Model Number: Sorandydfpne6kbx4

ASIN: B0H6J51NHX