

C CRANE SoftSpeaker 2 Pillow Speaker with Volume Control **User Guide**

Home » C CRANE » C CRANE SoftSpeaker 2 Pillow Speaker with Volume Control User Guide 🖫



Contents

- 1 C CRANE SoftSpeaker 2 Pillow Speaker with Volume **Control**
- **2 Washing Instructions**
- 3 Documents / Resources
 - 3.1 References
- **4 Related Posts**



C CRANE SoftSpeaker 2 Pillow Speaker with Volume Control



Instructions for use:

Plug the SoftSpeaker 2 into your radio's headphone jack. Adjust your radio's volume as needed. For maximum comfort, make an indentation in your pillow for the SoftSpeaker2. Frequency Response: 20Hz to 20kHz / High Frequency Dominant

Washing Instructions

To remove the speaker before washing, gently separate the cover at its center opening and slide the speaker out. Hand or machine wash cover in cold water, gentle cycle. Wash with dark colors, dry cool.

Other fine audio products from C. Crane:

CC Buds Solo In-Ear Single Earbud for Radio, Audio Books and Podcasts

The CC Buds™ Solo single earpiece provides a unique advantage over traditional earbuds because it allows you to interact better with others while listening to radio, podcast or audiobooks (your boss will love you). The integrated stereo to mono plug works with smartphones, radios, tablets and most other audio devices.



172 Main Street, Fortuna CA 95540 800-522-8863 • ccrane.com

Washable Cover One Year Warranty ccrane.com/warranty-registration-form/

Documents / Resources



<u>C CRANE SoftSpeaker 2 Pillow Speaker with Volume Control</u> [pdf] User Guide SoftSpeaker 2 Pillow Speaker with Volume Control, SoftSpeaker 2, Pillow Speaker with Volume Control, Speaker with Volume Control

References

- Portable Radios for Sale | AM/FM Radios & Antennas | C. Crane
- Warranty Registration Form

Manuals+