



DKS DOORKING Reverse Edge Barrier Gate Installation Guide

[Home](#) » [DKS DOORKING](#) » DKS DOORKING Reverse Edge Barrier Gate Installation Guide 



**REVERSE EDGE / RED GREEN
LED INSTALLATION**

DoorKing Part Numbers

8080-080

Reverse Edge

8080-096

Reverse Edge+ Red/Green LED

Contents

- [1 Reverse Edge Barrier Gate](#)
- [2 Installation](#)
- [3 Documents / Resources](#)
 - [3.1 References](#)

Reverse Edge Barrier Gate

This kit is designed to install on a 14 ft aluminum octagon arm for a 1601 barrier gate operator or a 1603 auto spikes operator.


It CANNOT be used with a 1602 operator.

Note: DO NOT operate arm with a malfunctioning reverse edge.


Installation

1. Remove End Cap

Push a screwdriver through hole in bottom of end cap to release spring while pulling cap off.




2. Slide on Stopper



3. Slide on Edge


Tip: Liquid soap will help reverse edge slide on easier.

4.




Reinstall End Cap

Push a screwdriver through the hole in cap to release spring while pushing cap on. Keep pushing cap on until a “CLICK” is heard which locks it in place.



Documents / Resources



[DKS DOORKING Reverse Edge Barrier Gate](#) [pdf] Installation Guide
Reverse Edge Barrier Gate, Edge Barrier Gate, Barrier Gate, Gate

References

- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.