



Elna eXtend 845 Professional with Overlocking Instruction Manual

[Home](#) » [Elna](#) » Elna eXtend 845 Professional with Overlocking Instruction Manual 

Contents

- 1 Elna eXtend 845 Professional with Overlocking
- 2 Product Information
- 3 Product Usage Instructions
- 4 FAQ
- 5 Optional Accessories
- 6 Documents / Resources
 - 6.1 References



Elna eXtend 845 Professional with Overlocking



Product Information

Specifications

- Model: elna 845
- Optional Accessories:
 - 200-810-007 Adjustable bias binder foot
 - 202-254-003
 - 202-247-003 Chain stitch foot (F) with 2 guides
 - 200-801-304 Cover hem foot (M)
 - 202-255-004 Blind stitch foot (D)
 - 200-807-001 Gathering foot
 - 200-808-002 Belt loop foot
 - 200-805-009 Multi-purpose foot
 - 200-809-003 Clear view beading and pearl foot
 - 200-803-306 Clear view chain stitch foot (F)
 - 202-248-004 Multi-purpose foot with 3 elastic gatherers
 - 200-802-202 Pintuck foot (K)
 - 200-814-104 Piping foot
 - 200-803-203 Felling guide (F-4)
 - 496-245-20 Taping foot (Q)
 - 200-801-108 Hem guide (H-2)
 - 797-812-004 Top cover foot (R)
 - 200-804-101 Topstitch covered stitch foot (N)
 - 200-803-007 Fagoting guide (F-2)
 - 200-801-005 Lace attachment guide (H-1)
 - 200-801-201 Wrapped edge guide (H-3)
 - 200-804-008 Topstitch guide (N-1)
 - 200-803-100 Lacing guide (F-3)
 - 200-802-006 Pintuck guide
 - 797-881-004 Quilt guide
 - 200-802-305 Cord guide
 - 797-343-009 Round thread guide
 - 200-812-102 Attachment holder support set
 - 200-814-001 Tape guide attachment
 - 396-001-42 Cloth guide deluxe
 - 797-342-008 Top cover hook
 - 200-811-008 Auxiliary thread guide
 - 200-805-102 Elastic gatherer 7.5 mm width
 - 200-812-009 Curve guide
 - 200-805-205 Elastic gatherer 10 mm width
 - 200-805-308 Elastic gatherer 13 mm width
 - 395-800-02 elna Serger tote
 - 797-866-106 Waste tray
 - 200-347-020 Universal manual needle threader
 - 494-805-006 Side pockets for sewing table sewing table

- 494-709-009 Side table without insert space
- 301-804-004 elna mat

Product Usage Instructions

Step 1: Setting up the elna 845

Before using the elna 845, make sure to set it up properly. Follow the steps below:

1. Place the sewing machine on a stable and flat surface.
2. Connect the power cord to a power outlet.
3. Insert the needle into the needle holder and tighten it securely.
4. Wind the thread onto the bobbin and insert it into the bobbin case.
5. Thread the upper thread through the machine following the threading diagram in the user manual.

Step 2: Selecting and Attaching Accessories

The Ina 845 comes with a variety of optional accessories. Follow the steps below to select and attach the desired accessory:

1. Refer to the user manual to identify the accessory you want to use.
2. Locate the accessory and ensure it is compatible with the elna 845.
3. Attach the accessory to the machine according to the instructions provided in the user manual.

Step 3: Operating the elna 845

Once the machine is set up and accessories are attached, you can start using the elna 845. Follow these steps:

1. Select the desired stitch pattern using the stitch selection dial.
2. Adjust the stitch length and width as needed using the corresponding controls.
3. Place the fabric under the presser foot, aligning it with the desired stitching line.
4. Lower the presser foot lever to secure the fabric.
5. Press the foot pedal gently to start sewing.
6. Guide the fabric along the stitching line, keeping it straight and steady.
7. Release the foot pedal to stop sewing.

FAQ

Q: Can I use accessories from other elna models with the elna 845?

A: The elna 845 is compatible with specific optional accessories listed in the user manual. It is recommended to use accessories designed for the elna 845 to ensure proper fit and functionality.

Q: How do I clean the elna 845?

A: To clean the elna 845, follow these steps:

1. Turn off the machine and unplug it from the power outlet.
2. Remove any loose threads or fabric scraps from the sewing area.
3. Use a soft, dry cloth to wipe the exterior surfaces of the machine.
4. If necessary, use a small brush or vacuum attachment to remove dust from hard-to-reach areas.
5. Avoid using liquid cleaners or submerging the machine in water.

Optional Accessories



200-810-007
Adjustable bias binder foot



202-254-003
Cover hem foot – 3 attachments: H-1, H-2 and H-3



202-247-003
Chain stitch foot (F) with 2 guides



200-801-304
Cover hem foot (M)



202-255-004
Blind stitch foot (D)



200-807-001
Gathering foot



200-808-002
Belt loop foot



200-805-009
Multi-purpose foot



200-809-003
Clear view beading and pearl foot



202-248-004
Multi-purpose foot with 3 elastic gatherers



200-803-306
Clear view chain stitch foot (F)



200-802-202
Pintuck foot (K)



200-814-104
Piping foot



200-803-203
Felling guide (F-4)



496-245-20
Taping foot (Q)



200-801-108
Hem guide (H-2)



797-812-004
Top cover foot (R)



200-801-005
Lace attachment guide (H-1)



200-804-101
Topstitch covered stitch foot (N)



200-801-201
Wrapped edge guide (H-3)



200-809-003
Clear view beading and pearl foot



200-804-008
Topstitch guide (N-1)



200-803-007
Fagoting guide (F-2)



200-803-100
Lacing guide (F-3)



200-802-006
Pintuck guide



797-881-004
Quilt guide



200-802-305
Cord guide



797-343-009
Round thread guide



200-812-102
Attachment holder support set



797-342-008
Top cover hook



200-814-001
Tape guide attachment



200-811-008
Auxiliary thread guide



396-001-42
Cloth guide deluxe












200-805-102
Elastic gatherer 7.5 mm width



200-812-009
Curve guide




200-805-205
Elastic gatherer 10 mm width

	200-805-308 Elastic gatherer 13 mm width		395-800-02 elna Serger tote
	797-866-106 Waste tray		494-805-006 Side pockets for sewing table sewing table
	200-347-020 Universal manual needle threader		494-709-009 Side table without insert space
	866-801-018 Accessory box – big model		
	843-823-004 Accessory box – small model		
	301-804-004 elna mat		

V1 10.2023

Subject to change without notice

Documents / Resources

	<p>Elna eXtend 845 Professional with Overlocking [pdf] Instruction Manual 845 Professional with Overlocking, 845, Professional with Overlocking, Overlocking</p>
---	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)