




HAY Pc Task Collection Instruction Manual

[Home](#) » [HAY](#) » HAY Pc Task Collection Instruction Manual 

HAY Pc Task Collection



Contents

- [1 GENERAL INFORMATION](#)
- [2 – CARE & MAINTENANCE](#)
- [–](#)
- [3 Customer Support](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)
- [5 Related Posts](#)

GENERAL INFORMATION

TECHNICAL DATA

This product is supplied with an integrated LED light source. The expected lifespan of the LED light source is 25,000 hours, which equates to 8-10 years of general use. When the light source reaches its end of life, the whole luminaire should be replaced.

FITTING TYPE | Integrated LED POWER (W) | 5,7W COLOUR TEMPERATURE | 3100K cool white


ATTENTION

Ensure that the power supply to the circuit has clearly been turned OFF before installing the product. In some countries, electrical installation must be carried out by authorised electricians/ contractors; please check with your local authority for guidance.

The product must not be modified in any way. HAY accepts no responsibility for any products that have been modified or tampered with. The external flexible cable or cord of this luminaire cannot be replaced. If the cord is damaged, the luminaire should be replaced. This lamp is designed for indoor use only.


CARE AND MAINTENANCE

The product can be cleaned with a soft damp cloth and mild detergent, or a dry micro fibre cloth. Do not use alcohol or any other solvents to clean the product and avoid using abrasive or rough sponges. Ensure that the power supply has been turned OFF before cleaning the product.




– PARTS –



- Lamp



- Allen key




- Adapter



- Screw



- Power supply



The lamp can be used with several different bases and fixings. Unpack all the parts and check that you have received all the parts listed.










Table Lamp only

Insert the lamp into the base (packed separately). Using the provided Allen key and screw, the lamp can be fixed to the base through a hole underneath.



Clamp only

Clamp the clamp base in place by adjusting the grip. Insert the lamp body into the clamp base.






Table Insert only


Carefully drill a 10 mm hole into a desktop where you would like the lamp to be positioned. Insert the table. Insert into the hole and tighten the circular nut underneath to hold firmly in place.




Wall Bracket only


With a pencil, mark fixing holes on the wall. Drill holes and insert wall plugs. Ensure you use the correct type of wall plug for the material you are drilling into.






Screw the internal bracket to the wall with the fixings provided and place the external plastic cover over the wall bracket.







Fix the external plastic cover in place with the provided screw. The groove on the side of the plastic cover provides simple cable management for the wall mounted lamp.




Insert lamp into the wall bracket and push the cable into the groove.




The lamp can be freely moved and will hold in any position.



If necessary, the joints can be adjusted using the provided torx tool. Carefully tighten the bolts until the lamp supports itself in any position.



Plug the trailing cable into the power supply. Attach the correct adapter for your region. The lamp is now ready for use.



– CARE & MAINTENANCE –

Our Care & Maintenance offers guidance for optimal maintenance of your HAY product. It includes advice and instructions on cleaning and caring for specific materials to prolong the life of your lighting.



Please find our Care & Maintenance guide by scanning the QR code



You can find more relevant information on PC Task Collection by scanning the QR code

you can also find the same information here hay.dk/downloads

Customer Support

Havnen 1 8700 Horsens Denmark

45 3164 6000 / hay@hay.com

<http://www.hay.com/>





[HAY Pc Task Collection](#) [pdf] Instruction Manual
Pc Task Collection, Pc, Task Collection, Collection

References

- HAY [HAY.dk – latest products, designer news and retailer info](#)
- HAY [HAY – Danish-Inspired Furniture + Accessories for Modern Living](#)
- HAY [HAY.dk – latest products, designer news and retailer info](#)
- HAY [hay.dk/hay-care-and-maintenance](#)
- V [VOCAST Digital Showroom](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.