


IMI C10.1 Compressor Connect User Guide

Home » IMI » IMI C10.1 Compressor Connect User Guide 🖺





WCMOIN0005 11.2022 **Compresso Connect** C10.1 / C15.1 / C10.2 / C15.2 **INSTALL**



Contents

- 1 C10.1 Compressor Connect
- 2 Documents / Resources
 - 2.1 References
- **3 Related Posts**


C10.1 Compressor Connect



















The texts, graphics and diagrams in this document may be subject to alteration without prior notice or reason being given. www.imi-hydronic.com






































1x 230V/50/60 Hz C.1: 10A / 3 x 1,0 mm² C.2: 16A / 3 x 1,5 mm²

















www.imi-hydronic.com
We reserve the right to introduce technical alterations without previous notice.



Documents / Resources



IMI C10.1 Compressor Connect [pdf] User Guide

C10.1 Compressor Connect, C10.1, Compressor Connect, Connect, Compressor

References

- IMI Hydronic Engineering A leading HVAC company
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.