

LIGHT and MOTION 800-0418-A Goodman Handle Instructions

Home » LIGHT and MOTION » LIGHT and MOTION 800-0418-A Goodman Handle Instructions

Contents

- 1 LIGHT and MOTION 800-0418-A Goodman Handle
- **2 Product Information**
- **3 Product Usage Instructions**
- **4 Mounting Instruction**
- 5 Documents / Resources
 - **5.1 References**
- **6 Related Posts**



LIGHT and MOTION 800-0418-A Goodman Handle



Product Information

• Product Name: Goodman Handle

• Model Number: 800-0418-A

• Compatibility: Sola 2L Mounting

• Additional Accessory: Ball Mount Thumb Screw (Sold Separately) Part # 800-0438-A

Product Usage Instructions

Mounting Plate Placement

- 1. Position the mounting plate between the Goodman Handle frame with the recess slot for bolt heads facing downwards.
- 2. For left-hand use, position the thumb rest on the right side and insert the mounting plate with the extended slot facing back towards your arm.

• Thumb Screw Installation

Secure the plate position by tightening both thumb screws.

Bungee Cord Attachment

- 1. Feed the open end of the bungee cord through the hole in the bottom of the thumb rest and tie an overhand knot, pulling the knot into the hole.
- 2. Once the fit is confirmed, cut the tail of the cord with scissors. Ensure to hold the end under a flame to seal it from unraveling.

Sola 2L Mounting

Remove mounting accessories from the Goodman Handle.

Learn more at support.lightandmotion.com

Q: What should I do if I need to purchase additional accessories like the Ball Mount Thumb Screw?

A: You can purchase the Ball Mount Thumb Screw separately with Part # 800-0438-A. Contact our customer support for assistance.


Mounting Instruction

• Step 1. Mounting Plate Placement:

- Position the mounting plate between the Goodman Handle frame with the recess slot for bolt heads facing downwards.
- For the left hand: position the thumb rest on the right side and insert the mounting plate with the extended slot facing back toward your arm.


• Step 2. Thumb Screw Installation:

Secure the plate position by tightening both thumb screws.



Step 3. Bungee Cord Attachment:


- Feed the open end of the bungee cord through the hole in the bottom of the thumb rest and tie an overhand knot, pulling the knot into the hole.
- Once the fit is confirmed, cut the tail of the cord with scissors. Make sure to hold the end under a flame to seal it from unraveling.



• Step 4. Sola 2L Mounting:

Remove mounting accessories from your Sola.

- Attach the ½-20 mount adapter to the Goodman handle plate using the ½-20 bolt. Make sure the tab with the hole is facing forward.
- Slide your Sola light onto the mount adapter from the back to the front until the adapter tab hole lines up with the threaded insert on the Sola body.
- Screw in the 10-32 with washer through the Goodman handle plate into the threaded insert in the Sola.
 Do not over-tighten.



Note: Refer to the exploded view for part identification.

Learn more at support.lightandmotion.com.



Documents / Resources



LIGHT and MOTION 800-0418-A Goodman Handle [pdf] Instructions 905-0497-A, 800-0418-A, 800-0418-A Goodman Handle, 800-0418-A, Goodman Handle, Handle

References

<u>O Light and Motion Help Center</u>

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.