

[Skip to content](#)

Manuals+

User Manuals Simplified.



litter robot 3 Backup Battery Kit Installation Guide

[Home](#) » [litter robot 3](#) » litter robot 3 Backup Battery Kit Installation Guide

Contents [hide](#)

[1 Litter-Robot® 3 UB1213k Backup Battery Installation Guide](#)

[1.1 Installation](#)

[1.2 Important Precautions](#)

[2 Documents / Resources](#)

[2.1 References](#)

[3 Related Posts](#)

Litter-Robot® 3 UB1213k Backup Battery Installation Guide



The Backup Battery (model UB1213k) provides up to 48 hours of operation if power is interrupted. Estimated operation time is based on 10 cleaning cycles per day (which is typical of two cats), but results will vary.

When power is interrupted, the unit will automatically switch to battery power and a yellow light will illuminate the Power button on the Control Panel. To conserve energy, the Night Light will not function. The Litter-Robot will switch back to household power when it returns, and the unit will begin recharging the battery.

Backup Battery Kits can be ordered at www.litter-robot.com.


Installation



*Battery pocket
on underside of
Base with leads*



*Connect leads
to terminals
according unit's
serial number*



*Attach battery
Retainer with
screws*

1. Press the Power button to turn the unit off , then unplug the unit.
2. Remove the Bonnet and Globe.
3. Locate the unit serial number.
For units purchased before October 5, 2017:
 The serial number is located on the inside back wall of the Base. You will need to remove the Waste Drawer to see the sticker.
For units purchased after October 5, 2017:
 The serial number is located on the exterior backside of the Base to the right of the power jack.
4. Gently turn the unit over to access the battery pocket on the underside of the Base.
5. According to the serial number, connect the battery leads as follows:
Serial numbers 934 and above:
 Connect the RED lead to the RED terminal.
 Connect the BLACK lead to the BLACK terminal.
Serial numbers 0-933:
 Connect the RED lead to the BLACK terminal.
 Connect the BLACK lead to the RED terminal.
6. Insert the battery into the pocket, so the connected side goes into the Base first.
7. Align the Retainer across the bottom of the battery and attach using screws provided.
 Visit www.litter-robot.com for installation videos.
8. Reassemble the Waste Drawer, Globe, and Bonnet, then plug the unit in and turn it on.

Important Precautions

- Lead acid batteries like this one must be disposed of properly. Please contact your local recycling center for

information on how to recycle this battery. Do not throw away the battery.

- In the event of a battery leak, make sure to vent the area as much as possible. Use gloves and avoid direct contact with the battery acid during cleanup. Battery acid can be neutralized with a paste of baking soda and water. Along with the battery, gloves and rags should be placed into a plastic bag and taken to your local recycling center for proper disposal.
- The battery must be removed from the unit before it is scrapped.
- The unit must be powered off and unplugged when removing the battery.



Headquarters

1080 W. Entrance Dr.
Auburn Hills, MI 48326


Assembly

561 S Fairfield Ave
Juneau, WI 53039

Contact Customer Service

Monday – Friday, 9am – 5pm EST
1-877-250-7729 or support@litter-robot.com

Documents / Resources



[litter robot 3 Backup Battery Kit](#) [pdf] Installation Guide
Backup Battery Kit

References

- [litter-robot.com](https://www.litter-robot.com)
- [Automatic, Self-Cleaning Litter Box for Cats | Litter-Robot](#)

[Manuals+](#),

- [home](#)
- [privacy](#)