

LUMINOX Flashlight Light Capsule For 0 29-32in Bandwidth User Manual

Home » LUMINOX » LUMINOX Flashlight Light Capsule For 0 29-32in Bandwidth User Manual



LUMINOX Flashlight Light Capsule For 0 29-32in Bandwidth User Manual



Thank you for using our Luminox Light Capsule! The Luminox Light Capsule is a reliable, durable, and easy to carry lighting solution ready for adventure.

Contents

- 1 Product features
- 2 Product specifications
- 3 Extent of delivery
- 4 How to install the

batteries

- 5 How to operate
- 6 Documents / Resources
 - **6.1 References**
- 7 Related Posts

Product features

Compact and simple design, weatherproof and convenient to carry. Single brightness mode, suitable for outdoor, camping or daily use.

Product specifications

Luminosity of light: 60LM

Run time: 60 minutes Light range: 10 meters

Service life of LED: up to 50'000 hours

Water resistant: IPX-8 Shockproof: 1,5 meters

Dimension of light capsule: 40 x 11.5/14.50mm **Weight of light capsule:** 9 grams (incl. batteries)

Dimension of holder: 32 x 14.50mm

Weight of holder: 4 grams

Batteries: 3 x 1.5V LR754 button batteries

Remark: This data is from laboratory tests, actual use will vary depending on the environment or battery type.

Extent of delivery



- On/off button
- · Light capsule head
- · O-Ring gasket
- Batteries
- · PLight capsule body
- · Light capsule holder

How to install the batteries

1. Screw off the orange head.

- Place the 3 batteries in the orange head (order does not matter).The protective film shall be removed before installing the batteries.
- 3. Screw the orange head back into the black body of the light capsule.

How to operate

Once the batteries are in, press the on/off button once to turn the light capsule on. Press the on/off button a second time to turn the light off.

Maintenance and precautions

- When replacing the batteries, it is recommend to use high quality batteries to preserve the life of your light capsule.
- Do not point the light directly in the eyes to avoid injury.
- Keep the light capsule out of direct sunlight, water, chemicals or corrosive gas for extended periods of time to avoid damages.
- It is recommended to lubricate the threads 2-3 times a year to ensure smooth screwing and unscrewing of the orange head.
- To clean the light capsule, use a soft brush or towel.
- To avoid corrosion, it is recommended to remove the batteries when not in use for extended periods of time.
- Seek professional help when dissembling the contents beyond changing the batteries of light capsule to prevent damage.





Documents / Resources



<u>LUMINOX Flashlight Light Capsule For 0 29-32in Bandwidth</u> [pdf] User Manual Flashlight Light Capsule For 0 29-32in Bandwidth

References

• **□** LuminoxWorld - YouTube

