

※ Thanks for selecting the EPEVER WiFi 2.4G RJ45 D adapter; please read this manual carefully before using the product.

※ Do not install the product in humid, salt spray, corrosion, greasy, flammable, explosive, dust accumulative, or other severe environments.

WiFi Adapter

EPEVER WiFi 2.4G RJ45 D

1. Overview

Through a local 2.4G WiFi network, the EPEVER WiFi 2.4G RJ45 D can transmit all operational data from the EPEVER solar controller, inverter, or inverter/charger to the EPEVER cloud server in real time. Users can remotely monitor the connected devices and program parameters via the EPEVER server platform and mobile APP.

Features

- Applicable to EPEVER controllers, inverters, or inverter/charger with RJ45 port
- Use immediately after connecting; easy and convenient operation
- Directly powered by the communication port
- Up to 20 meters of communication distance
- Support the Local monitoring and "EPEVER Cloud" working mode.

2. Appearance



① **RJ45 connector:** Connect to the RJ45 port of the controller, inverter, or inverter/charger. RJ45 Pin Definition:



Pin	Definition	Pin	Definition
1	+5VDC	5	RS485-A
2	+5VDC	6	RS485-A
3	RS485-B	7	GND
4	RS485-B	8	GND

3. Specifications

Parameter	Model	EPEVER WiFi 2.4G RJ45 D
Working voltage		5V± 0.5V(Powered by RS485 com. port)
Power consumption		Peak emission: 150mA; Idle: 310uA
Enclosure		IP30
Communication method		RS485
Communication parameters		115200Bps, 8N1
Interface standard		EPEVER communication standard V1-1.0
Work frequency		2.4 ~ 2.4835GHz
Work temperature range		-40°C~ 85°C
Dimension		63mm x 19mm x 10mm
Net weight		7.7g

Note: The WiFi adapter working voltage is 4.5V~5.5V and peak emission is 150mA, which is only suitable for devices that meet this requirement.

4. Working processes



① Connect the WiFi adapter to the RJ45 port of the EPEVER device. ② Add the WiFi adapter into the EPEVER cloud by the PC or mobile APP. **WARNING:** The WiFi adapter is not available to the LS-B series. Suppose the WiFi adapter is installed in a metal-confined space. In that case, the signal transmission will be influenced, depending on the material and tightness of the metal-confined space.

✧ **Scenario 1: There is a local 2.4G WiFi network.** The WiFi adapter can upload the collected data to the EPEVER cloud automatically.

Step1: Turn on the WiFi switch on the mobile phone, and connect to the local WiFi network (a **2.4G WiFi network is a must**).

Step2: Login to the APP and click the **My** icon to add a new gateway.

Step3: Select the gateway model.

Step4: Input the gateway data ("**Gateway SN**" is the **22-digit number of the gateway WiFi name**), and click "Next Step" to enter the device adding page.

Step5: After adding the device, click "Next Step" to enter the above page.

Step6: Input the local WiFi password and click "Next Step."

Step7: Click "Go to set up Wi-Fi" to connect phone to the gateway WiFi (HN_EPSN: xxxxxx, password: 12345678). Return to the APP after connection, and click "Next Step."

Step8: After the gateway is successfully connected, connect the phone to local WiFi or 4G that can access the Internet. Then you can monitor the device through the APP.

✧ **Scenario 2: There is no local 2.4G WiFi network.** The WiFi adapter cannot upload the collected data to the EPEVER cloud.

Step1: Login to the APP and click "My > Collect Data." Select all products and click the "Synchronize data" to download data.

Step2: After all data is downloaded, return to the APP. Click the "Home > Offline."

Step3: Select the module type (WiFi)

Step4: Turn on the phone WiFi switch and connect the phone to the gateway WiFi (HN_EPSN: xxxxxx, password: 12345678).

Step5: Return to the APP and click "Equipment>Add equipment" ("**Gateway SN**" is the **22-digit number of the gateway WiFi name**). Click "Confirm" to add the device.

Step6: On the "Device List" page, click the gateway SN to enter the device's real-time monitoring page.

Any changes without prior notice! Version number: V1.1