

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Technical Support and E-Warranty Certificate www.vevor.com/support

TOWEL WARMER CABINET

MODEL:RTD-8L

We continue to be committed to provide you tools with competitive price.


"Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and does not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually saving half in comparison with the top major brands.

VEVOR[®]

TOUGH TOOLS, HALF PRICE

TOWEL WARMER CABINET

MODEL:RTD-8L



NEED HELP? CONTACT US!

Have product questions? Need technical support? Please feel free to contact us:

Technical Support and E-Warranty Certificate
www.vevor.com/support

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

	Warning-To reduce the risk of injury, user must read instructions manual carefully.
	This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:(1)This device may not cause harmful interference, and (2)this device must accept any interference received, including interference that may cause undesired operation.
	This product is subject to the provision of European Directive 2012/19/EC. The symbol showing a wheeled bin crossed through indicates that the product requires separate refuse collection in the European Union. This applies to the product and all accessories marked with this symbol. Products marked as such may not be discarded with normal domestic waste, but must be taken to a collection point for recycling electrical and electronic devices

FOR YOUR SAFETY

Read all instructions carefully, even if you are familiar with the appliance.

- Young children should be supervised to ensure that they do not play with the appliance.
- Always unplug the warmer when not in use.
- Do not operate the warmer with a damaged cord or plug or after the warmer malfunctions, has been dropped or damaged in any manner.
- Never locate the warmer where it may fall into a bathtub, shower, swimming pool or any other water container.
- Towels, Steam, Rack, Tray and inside surfaces of appliance are HOT and can be dangerous. Pay your special carefulness when reloading or removing hot towels, racks or trays out of the unit. Always use protective gloves when handling hot tray, rack or towels.
- To avoid burns, do not put "hot" towels right taken out from a towel warmer on any bare surfaces of human's bodies.
- Do not place heavy objects or a container water in or on top of the

cabinet.

- Do not use the door left opened. Do not run power cord under carpeting.
- Do not cover cord with throw rugs, runners or the like. Arrange cord away from traffic areas and where it will not be tripped over.
- To disconnect the warmer, set control to OFF and then remove the plug from the outlet.
- Do not abuse the cord. Never carry the appliance by the cord or yank it to disconnect it from an outlet; instead, grasp the plug and pull to disconnect.
- Do not attempt to repair, disassemble or modify the appliance. There are no user-serviceable parts.
- Use the unit only as directed in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock or injury to persons.

COMPULSORY WARNING


- No user serviceable parts inside. **Unauthorized** modification voids warranty.
- Before first using your Towel Warmer, it is most important that you read and follow the instructions in this use and care booklet, even if you feel you are quite familiar with this type of appliance.
- Your attention is drawn particularly to the section dealing with IMPORTANT SAFEGUARDS. Find a place and keep this booklet handy for future reference.
- Your Towel Warmer is safe and easy to use. It has been designed to function quietly and safely under normal circumstances.
- Check that the voltage marked on the product corresponds with your supply voltage.

Warning: This appliance must be earthed.

Cautions: When the device is turned on, it will take some time to start heating.

INSTRUCTIONS

Thank you very much for choosing this towel warmer cabinet. Please read all of the instructions before using it. The information will help you achieve the best possible results.



PRODUCT PARAMETER

Model	RTD-8L	
District	North America	Europe
Power	AC 110-120V 60Hz	AC220V-230V 50/60Hz
Wattage	130W	
Capacity	8L	
Net Weight	3.00kg	
Product Size	300*300*255mm	

PACKAGE DETAILS

NO.	ACCESSORY NAME	QUANTITY
1	Towel Warmer Cabinet	1
2	Wire Baskets	1
3	Towel Clip	1
4	User Manual	1

BEFORE OPERATION

- Be sure to remove all packing material before use.
- Place the unit on a well ventilated, flat, sturdy surface away from heat sources. The unit should not be used in the immediate vicinity of water (such as bathtub, washbowls, etc.) where the likelihood of immersion may occur. Keep at least 30mm away from walls and other objects.
- Plug cord into a power outlet.
- Remove the wire basket and set aside.

OPERATION

1. Please fold or roll up the damp or pre-moistened towels but not soaked ones into the wire basket of hot towel warmer. Try to wring out the water several times to shorten the heating time.
2. The inside wall temperature is 158-176°F. 100% cotton dry towels could be put as well but not any other cloths which couldn't bear this high temperature, and keep it within less than 2 hours heating. Please keep the towel away from the inner wall of warmer.
3. Do not overload the wire basket or directly place towels into the towel warmer.
4. Close the door firmly and press the Power button to turn on. The indicator near the switch will be on to show that the towel cabinet has started heating.

5. In about 1.5-2.5 hours, depending on how many towels you put inside, while keeping the door closed, the temperature inside the cabinet will heat up to approximately 158-176°F and will be kept automatically. Avoid opening cabinet when towels are heated.
6. Turn off the power button whenever you want to add more towels. The heating process will be restarted. The thermostat will automatically stop working when temperature reaches 158-176°F. It's safe to keep it on.
7. If desired, press the UV button to turn on EPA-registered UV sterilization system. The indicator near the switch will be on to show that the UV light is working. Wait 30 minutes for the sterilization process to complete.
8. Whenever you want to open the door, please first turn off the power with the indicator light off. Stay a safe distance from the cabinet door opening to avoid being burned by high-temperature steam from the cabinet. Remove towels with tongs or heat-resistant gloves.
9. Towels may be too hot to apply immediately, and caution should be used before applying to the face or body.

MAINTENANCE

1. Turn OFF the unit.
2. Unplug the cord from the outlet.
3. Wait for contents to cool before handling. Contents may be hot. Remove the wire basket and towels. Set the wire basket aside to dry.
4. With a soft cloth, wipe down the internal surfaces. Do not use harsh chemicals or abrasives. To clean exterior, use a soft cloth and mild soap.
5. Pull the drip tray forward and empty contents. Set the drip tray aside to dry.

TROUBLESHOOTING

1. There is excessive moisture when the towel warmer is ON or the towels are heating up very slowly. Check to see that the towels are only slightly damp. Excess moisture and/or slow heating time may be a result of soaked towels.

2. The door is not closing properly and/or steam is escaping Check that the silicone door seal is in place. Push into door groove to assure proper fit.

CORRECT DISPOSAL



This product is subject to the provision of European Directive 2012/19/EC. The symbol showing a wheelie bin crossed through indicates that the product requires separate refuse collection in the European Union. This applies to the product and all accessories marked with this symbol. Products marked as such may not be discarded with normal domestic waste, but must be taken to a collection point for recycling electrical and electronic devices

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Technical Support and E-Warranty Certificate

www.vevor.com/support