




QUICK START GUIDE



a



b



c



d



e



f



g

English

- | | | | |
|--|---------------|--------------------|--------------|
| ① Power key/fingerprint key | ② Indicator | ③ Type-C interface | ④ Microphone |
| ⑤ Handwritten ink screen | ⑥ TF/SIM slot | ⑦ Front camera | ⑧ Horn |
| ⑨ Magnetic adsorption charging port of electromagnetic pen | ⑩ Rear camera | | |

- a. Equipment b. Product c. Warranty Card d. Type-C data cable
e. Intelligent electromagnetic pen f. Cartridge g. Cartridge clip

Use skills:

1. How to turn on/off

- 1.1 Under the shutdown state, press the power key for 5 seconds to enter the opening interface, and the main operation surface;
1.2 Long press the power button for 1 second to pop up the shutdown dialog box, select shutdown or restart;
1.3 Long press the power button for 12 seconds to reset and restart.

2. How to recharge

- 2.1 Please charge through a data cable using a 5V–2A power adapter meeting the safety specification requirements;
2.2 The intelligent office tap is charged by a standard data cable connected to the computer USB port;
2.3 During the charging process, the white indicator of the on/off key is always on, and the indicator goes out after being fully charged;
2.4 It may be charged fully in about 4–5 hours.

3. How to transmit data

- 3.1 The intelligent office tap is transmitted through a USB cable connected to the computer;
3.2 It is synchronously transmitted through the Cloud Literacy APP.

4. How to perform WIFI transmission

- 4.1 Enter the application "Offline books" – Click "Import" in the top right corner of the page – Select WiFi import;
4.2 Connect the intelligent office tap and the computer to the same WiFi hotspot, and enter the pop-up URL of step 1 in the computer browser;
4.3 Select local files to import and upload files (up to 10 files once).

5. How to do the OTA upgrade

Enter settings – more settings – system update – enter OTA online update

Note: Please make sure that the equipment power supply is greater than 30% before upgrading.

Note:

1. There is an explosion hazard if replacing batteries of the wrong model. Be sure to dispose the exhausted battery based on the instructions.

2. This product is sold without a power adapter. If powered by a power adapter, please purchase 5V-2A power adapter that meets the safety specification requirements;



Do not crush
the fragile screen



Do not dismantle the
machine without permission



Stay away from
liquid with batteries inside



Service
environment 0°C~45°C

FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and**
- (2) this device must accept any interference received, including interference that may cause undesired operation.**

Note: This equipment has been tested and found to comply with the limits for a Class

B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television

reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.