

LA CROSSE®
TECHNOLOGY

ATOMIC DIGITAL CLOCK



SET UP GUIDE

MODEL: WT-8005U-B


POWER UP

1. Insert 2-AA batteries into your Digital Clock.
2. After Power Up, your clock will search for the Atomic Time Signal for 7 minutes. *Buttons will not function during the search.* When Atomic Time Signal (📡) is received, the clock will set itself to the Pacific time zone (default). Press the **ZONE** button to select your time zone.

OR

3. Press the **SEARCH** button to stop the initial Atomic Time Search and set the time manually.
 - The clock will search for the Atomic Time Signal again after midnight.
 - Press **SEARCH** button anytime, to start an Atomic Signal Search.

For more information on Atomic Time visit: bit.ly/atomic_time



SETTINGS MENU

1. Hold the **SET** button until the display changes to enter the Settings Menu. Press and release the **+** or **-** buttons to adjust values. Hold to adjust quickly.
2. Press and release the **SET** button to confirm values and move to the next setting.
3. Press and release the **SNOOZE** button at any time to exit.

Settings Menu Order:


- 12/24 Hour
- Hour
- Minutes
- Year
- Month
- Date
- DST on/oF (ON/OFF)

Weekday: Your weekday display will adjust automatically once you have your Year, Month, and Date settings set correctly.

TIME ZONE SELECTION

Press and release the **ZONE** button to select from four North American Time Zones:

P = Pacific • **M** = Mountain • **C** = Central • **E** = Eastern



FAHRENHEIT / CELSIUS

Press and release the °F/°C button to select Fahrenheit or Celsius temperature display.

TIME ALARM

Set Alarm Time:

1. Hold the **ALARM** button to enter the Alarm Settings Menu. The Seconds will be replaced by the letters “**AL**”.
2. The Alarm Hour will flash. Use the +/- buttons to adjust values.
Press the **ALARM** button to confirm and move to the minutes.
3. The Alarm Minutes will flash. Use the +/- buttons to adjust values.
Press the **ALARM** button to confirm and exit.

Activate/Deactivate Alarm:

Setting the alarm time and activating the alarm are separate steps.

1. Press the **ALARM** button to view the alarm time.
2. Press and release the + (**PLUS**) button to activate or deactivate the Time Alarm.
3. The Alarm Icon  will appear when active and will disappear when inactive.

Snooze:

- When the alarm sounds, press the **SNOOZE** button to silence the alarm for 5 minutes.
- Press any button (except SNOOZE) to silence the alarm for 24 hours.

RESET BUTTON

- If the Digital Clock display appears distorted or is not responding to buttons, use a pen or paper clip to press the **RESET** button one time.
- This will reset the atomic clock to default settings.

We're Here to Help

If you require additional assistance, get in touch with our friendly customer support team based in La Crosse, WI.

Self Help: bit.ly/wt-8005u-b_support

Online: bit.ly/contact_techsupport

Phone: 1.608.782.1610

Our knowledgeable customer support team is available:
Mon-Fri 8am-6pm CST

Stay in Touch!

Ask questions, watch set up videos, and provide feedback on our social media outlets. Follow La Crosse Technology on Youtube, Facebook, Instagram, and X (Twitter).



⚠ WARNING: This product can expose you to chemicals including acrylonitrile, 1, 3-butadiene, and styrene, which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to: www.P65Warnings.ca.gov


SCAN HERE
Additional Info
and Support ✓



SPECIFICATIONS

Atomic Clock: WT-8005U-S

- **Temperature Range:** 32°F to 122°F (0°C to 50°C)
- **Update Interval:** About every 51 seconds
- **Power:** 2-AA, IEC, LR6 batteries (not included)
- **Battery Life:** 24+ months
- **Dimensions:** 8.9" L x 1.2" W x 7.2" H (22.60 L x 3.04W x 18.2 H cm)



WARRANTY & PATENTS

La Crosse Technology Ltd. provides a 1-year limited-time warranty on this product relating to manufacturing defects in materials & workmanship. In accordance with the Song-Beverly Act, in the state of California, the warranty on this item becomes effective on the date of delivery.

La Crosse Technology, Ltd, 2830 S. 26th St., La Crosse, WI 54601

For Full Warranty Details, Visit: www.lacrossetechnology.com/pages/warranty

Patents: www.lacrossetechnology.com/pages/patents

CARE & MAINTENANCE

Battery Replacement Instructions

When batteries of different brand or type are used together, or new and old batteries are used together, some batteries may be over-discharged due to a difference of voltage or capacity. This can result in venting, leakage, and rupture and may cause personal injury.

- Always purchase the correct size and grade of battery most suitable for the intended use.
- Always replace the whole set of batteries at one time, taking care not to mix old and new ones, or batteries of different types.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries are installed correctly with regard to polarity (+ and -).
- Remove batteries from product during periods of non-use. Battery leakage can cause corrosion and damage to this product.
- Remove used batteries promptly.
- For recycling and disposal of batteries, and to protect the environment, please check the internet or your local phone directory for local recycling centers and/or follow local government regulations.

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Caution!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

All rights reserved. This manual may not be reproduced in any form, even in part, or duplicated or processed using electronic, mechanical or chemical process without the written permission of the publisher. This booklet may contain errors or misprints. The information it contains is regularly checked and corrections are included in subsequent editions. We disclaim any responsibility for any technical error or printing error, or their consequences. All trademarks and patents are recognized.



LA CROSSE®
TECHNOLOGY

