# INSTALLATION ALTA - MICRO 5 SERIES




#### Mounting NOTE: 2 clips provided for 4' or less; 4 clips provided for greater than 4'


Stainless Steel Clip (SST-08)




## Screw Mounting



## Millwork Mounting - SST Clip




## 832 Silicone Mounting



NOTE: Apply silicone in a well ventilated area. 832 Silicone is sold with caulking gun. Do not use in any submersible applications.

## VHB Mounting




NOTES: • Field modifications must comply with Q-Tran's installation methods otherwise warranty is null and void


## INSTALLATION ALTA - MICRO 5 SERIES



## **Mounting**



## Magnet Mounting




Using the #6 Flat head screws, mount screws into the magnet bracket through the drilled holes.

Adjust magnet location by applying rubber stoppers.

Connect the assembled fixture to the magnet bracket, the install should match the section view.

NOTE: The magnet clips should be offset to the flat heads used to secure the bracket, to maximize magnetic connection.

### Millwork Mounting - Magnet



NOTE: For millwork with magnets, adhesive must be used to complete install.