VEVOR

Affordable. Reliable. Home Improvement.

DRYER VENT KIT

MODEL:HG-03



MODEL:HG-03



This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.


Safety Instructions

Read and understand this entire manual before assembling, installing, operating, or servicing this product. Failure to follow these warnings and instructions can cause personal injury or damage to valuable property.


WARNING: Please carefully read the following instructions in order to reduce the risk of injuries, accidents or damage to the product by itself.

- 1. Products shall be installed by adults;
- 2. Products are installed away from children and pets;
- 3. Please wear gloves to install the product to avoid hand injury;
- 4. This product is only suitable for indoor use

PART LIST



STRUCTURE DIAGRAM AND COMPONENTS



INSTALLATION AND INSTRUCTION

Location: Ensure that the dryer vent is located on a vertical wall and close

to the electric clothes dryer. Avoid venting to areas such as the attic, eaves, ridge vents, or crawl space.

Height: Install the vent at a height that is easy for users to operate for easy cleaning and maintenance.

Duct type: It is recommended to use any UL certified dryer transition pipe; do not use vinyl hose.

Connection: We recommend using a metal 90 degree elbow (also known as a "right Angle elbow") on the back of the dryer to prevent the transition hose from being squeezed against the wall. This elbow needs to be purchased separately.

Note: The exhaust pipe can be installed using a hose clamp or torsion spring, depending on the actual situation.

1.Install the filter cotton on the upper cover first, and then press the metal filter screen over the filter cotton.



2. Tighten the screw on the hose clamp and secure the exhaust pipe to the Upper cover.




3. The maximum capacity of the tank is 1.5L, and we recommend adding 0.4L of water for use.




4.Install the lid with the exhaust pipe on the tank, and make sure that the two clips on the lid are tight on the tank.




5.Use screws to secure the plastic card to the wall near the dryer. It is recommended that you measure the length of the exhaust pipe you purchased to see if it can be connected to the dryer from here.




6.Insert the tank connector into the groove of the plastic clip to complete the fixing of the dryer vent.



7.Connect the other end of the exhaust pipe to the dryer and clamp it with a hose clamp.



8.If your dryer is close to the wall, we recommend that you purchase a metal 90 degree elbow for yourself and install it on the dryer to avoid damage and poor exhaust due to folding of the exhaust pipe.



Maintenance and cleaning

- 1.Remove the upper cover and clean the built-in filter cotton and filter screen;
- 2.Clean the filter screen with a brush once every 3 to 5 batches of clothes have been dried.
- 3.Replace the filter cotton or use a vacuum cleaner to suck away the lint on the cotton after every 5 to 8 times of drying clothes. Do not wash the filter cotton with water.
- 4.If there is water in the tank, drain the water from the tank and wash the cotton in the tank every 3-5 times you dry your clothes.
- 5. If the dryer vent is not used for a long time, do not add water to the tank.

Manufacturer: Shanghaimuxinmuyeyouxiangongsi

Address: Shuangchenglu 803nong11hao1602A-1609shi, baoshanqu,

shanghai 200000 CN.

Imported to AUS: SIHAO PTY LTD. 1 ROKEVA STREETEASTWOOD

NSW 2122 Australia

Imported to USA: Sanven Technology Ltd. Suite 250, 9166 Anaheim

Place, Rancho Cucamonga, CA 91730

UK REP

YH CONSULTING LIMITED. C/O YH Consulting Limited Office 147, Centurion House, London Road, Staines-upon-Thames, Surrey, TW18 4AX

EC REP

E-CrossStu GmbH Mainzer Landstr.69, 60329 Frankfurt am Main.

