Search Light Self-Iearning Manual

OPERATION:

- 1. Turn on the power of the remote. The power switch is at left side of remote. Please refer to Fig.1.
- 2. Press lamp "on" button once, the lamp will turn on steadity. At this time, you can adjust the direction of the light beam by pressing the direction button.
- 3. To turn off the lamp, just press "off" once button.

SOS CODE LEARNING PRECEDURE:

1. Press both ← and ↓ button simultaneously on the remote within two seconds after power on the main unit, If the light flashes, the code learning completes.

REMARK:

If your remote loses or you can't find out your remote, you may use another remote by learning the following precedure:

- 1.Press "on" botton without moving away.and make sure if the signal light is on.
- 2. Then connect the electricity.
- 3. After your light is on, then you can normal operate.
- 4. Please note that you can only use 1 remote for one main unit.





This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction