

Dry Ice Fog Machine User Manual



Kindly please read this manual carefully before operating the machine.

Thank you for purchasing our product! Please kindly read the manual carefully and operate the machine strictly to it for better operating and your safety, and in case of any bodily injury or damage to the unit.

Operation

1. Open the upper cover of the machine, pour water into the water tank about 8L. The water should reach just to the bottom of the basket when the basket is fully raised. The red heating light will come on when there is sufficient water.
2. Preset the temperature switch to 70-80 °C.
3. Power the unit on ,The RED light(heating) on the panel lights up. If there is not enough water, this light will not turn on.
4. Waiting for the water to get hot. About 15Mins till the GREEN light on the panel lights up.
5. When the GREEN light is on, we open the upper cover , add about 3kg of dry ice to the dry ice basket, and then close the upper cover quickly.
6. Put down the lifting handle that controls the dry ice basket, and a large amount of smoke will be sprayed out from the smoke outlet immediately. The lifting handle has 2 adjustable water levels. Put it at the bottom to spray the maximum amount of smoke. When such a large amount of smoke is not required, you can put it in the first gear, which can save dry ice.

Warning

1. The input of the power supply must be connected to the ground, otherwise, the leakage protection won't work.
2. Enough water must be poured into the water tank before electrification, otherwise, the machine won't work because of water-shortage protection.
3. After each use, drain the water in the water tank.
4. Because the temperature of dry ice is very low, be careful every time you touch dry ice, and use thick cotton gloves or other shelter to touch dry ice! If you touch the skin directly for a long time, it may cause cell freezing and similar slight or extremely serious frostbite.

Technical Parameters

POWER:220V 3500W / 110V 2000W

Voltage: 110V 60HZ / 220V 50HZ

Control: Manual

Supplies: Columnar dry ice

Preheating time:220V 15Mins (110V 25Mins)

Electronic temperature control: 70°C~80°C

water consumption: 8L

Maximum continuous output time: 2-3minutes

Cover area: about 150 square feet

Weight: 7.8kg

SIZE: 42*36*40cm

Packing Size:49*45*46.5CM
Flay case size: 50*43*55CM

Packing Weight: 12.3kg
Flay case weight: 21kg