



WELDING HEAD SHIELD - SHADE 10

MODEL NO: **SSP101.V2**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to
instructions

1. SAFETY

- ✓ Ensure all workshop safety rules, regulations and conditions are complied with when using welding equipment. The head shield will not offer protection against misuse of workshop tools, equipment, or accessories.
- ✓ This head shield is designed for eye and face protection during the following operations: manual metal arc welding, TIG welding, pulsed arc welding and plasma cutting.
- ☐ **WARNING!** This head shield is not suitable for use with laser welding or oxygen acetylene welding or cutting.
- ✓ Prior to using the head shield for the first time ensure that any protective film is removed from the internal and external lenses.
- ✓ Maintain the head shield in good condition.
- ✓ Ensure that the clear lens is kept clean and is securely attached to the head shield.
- ✓ Fit the head shield and adjust the head band so the head shield will sit as low and near to your face as possible.
- ✓ Use head shield only in temperatures ranging from -10°C to 60°C.
- ✓ Remove ill fitting clothing, remove ties, watches, rings and other loose jewellery.
- ✓ Maintain correct balance and footing.
- ✓ Ensure the floor is clear from obstructions, not slippery and wear non-slip shoes.
- ✓ Keep children and unauthorised persons away from the working area.
- ✓ Replace the lenses if they become scratched or covered in weld spatter.
- ☐ **WARNING!** The head shield will only protect the eyes/face from radiation and weld spatter.
- ☐ **WARNING!** The head shield will not protect against explosive devices or corrosive liquids.
- * **DO NOT** use the head shield for any purpose for which it is not designed.
- * **DO NOT** use the head shield unless you have been instructed in its use by a qualified person.
- * **DO NOT** get the head shield wet or use in damp or wet locations.
- * **DO NOT** leave work place with head shield in lowered position.
- * **DO NOT** place the head shield on a hot surface.
- * **DO NOT** use the head shield without the correct shade (filter) for the desired application.
- ☐ **WARNING!** During the welding process hazardous ultraviolet and infrared rays are emitted which can injure the eyes and cause skin burns.
- ✓ It is advisable to wear suitable additional safety clothing to protect the rest of the body during the welding process.
- ✓ After use, clean head shield and store in a safe, dry, childproof location in it's original packaging.
- ☐ **WARNING! DO NOT** use the helmet if damaged or you suspect it may be faulty. (Contact Sealey stockist).
- ☐ **WARNING!** Welding vapours and gases can be harmful to your health. Keep your head away from any fumes, work in a well ventilated area.

2. INTRODUCTION

Welding head shield with polypropylene shell and adjustable headband. Features a 2" x 4-1/4" front flip lens for quick and easy weld inspection. Supplied with a shade 10 lens. Conforms to BS EN 175.

3. SPECIFICATION





Model: SSP101.V2

Shade: 10

4. ASSEMBLY

4.1. ATTACHING THE HEADBAND

- 4.1.1. Unscrew and remove the thumb wheel on one side of the headband (fig 1).
- 4.1.2. Locate the exposed threaded spindle through the fixing hole in the head shield body (fig 2).
- 4.1.3. Clip the tilt tab onto the locating stud on the head shield (fig 3).
- 4.1.4. Reattach the thumbscrew and tighten (fig 4).
- 4.1.5. Repeat for the other side.



5. ADJUSTMENT

5.1. ADJUSTING THE HEADBAND CIRCUMFERENCE

5.1.1. Adjust the headband circumference with the thumb wheel (fig 5) located at the rear of the headband.

5.1.2. Turn clockwise to tighten and counterclockwise to loosen.



5.2. ADJUSTING THE HEADBAND HEIGHT

5.2.1. Adjust the height by snapping the pins on the top band (fig 6) of the headband into the desired position.

5.3. ADJUSTING THE HEADBAND TILT ANGLE

5.3.1. Adjust the tilt angle by loosening the thumbscrews (fig 2) on both sides of the head shield and change the tilt tab to the desired angle (fig 3). There are four pre-set positions to select.

5.3.2. Re-tighten the thumbscrews.



6. MAINTENANCE

6.1. REPLACING THE SHADE LENS

6.1.1. Flip up the front shade lens holder (fig 7).

6.1.2. Locate thumb or forefinger under the lens retainer clip (fig 8) and gently pull inwards and outwards and remove the lens retainer and place in a secure position.

6.1.3. Remove the shade lens and replace with a new one.



6.1.4. Replace the lens retainer by clicking back into place.

6.1.5. REPLACING THE CLEAR LENS

6.1.6. Locate thumb or forefinger under the lens retainer clip (fig 8) and gently pull inwards and outwards and remove the lens retainer and place in a secure position.

6.1.7. Remove the clear lens and replace with new one.

6.1.8. Replace the lens retainer by clicking back into place.



6.2. CLEANING

6.2.1. Clean with a soft cloth.

* **DO NOT** use solvents.



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. Please note that other versions of this product are available. If you require documentation for alternative versions, please email or call our technical team on technical@sealey.co.uk or 01284 757505.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk