

Installation manual




Indoor ventilation Passive air register with pollen filter

Please read carefully before installation

Nasta KS-86PR001FK

Body dimensions: 200mm square

Compatible with 150mm duct




Before installation

- Confirm duct is installed, and is the appropriate size for the vent
- Ensure duct is straight, without bends, steps, or deformation
- Check that the inside of the duct is clean and free of debris

Installation


- To prevent air and moisture leaking between the duct and the duct connector, attach the foam tape to the edge of the connector (before the step). Press firmly, without pulling



⚠ Precautions for attaching the tape


- Wipe any dust or dirt from the duct connector before attaching the foam tape
- When attaching, do not pull or stretch the tape
 - This will reduce the quality of the seal, leading to water or air leaking through
- Ensure the ends of the tape overlap at the top of the duct connector

- Insert the duct connector into the duct or pipe
 - Sealant or adhesive may be used if required




1. Remove the cover

1. Push the two opposite open sides of the cover in
2. Pull lightly away from the body



2. Remove the body cover

1. With the Nasta mark engraved on the body facing up, place your finger on the lowest grip.
2. Push down, and pull the body cover away from the body
3. Lift the body cover up and off the body




3. Perform caulking

1. Wipe away any dust or moisture
2. Ensure the body is not tilted before caulking as per the diagram


⚠ Precautions for caulking/sealing

- See the figure on the right for the range of caulk
- Do not caulk the clips, as this will prevent the body cover from being attached
 - Caulk should be thickness of 2mm or less
- Once solidified, reattach the main body cover



4. Reattach the cover and body cover

1. Attach the body cover, by performing the reverse of part 2 above. Ensure the Nasta mark is upright on the upper side
2. Align the cover with the body
3. Press the sides in, whilst pushing the cover lightly onto the body. This should clip into the grips on the body cover




Cleaning and maintenance

1. Remove the cover
2. Remove the filter cartridge by pinching the arms of cartridge, rotating counter-clockwise, and pull gently
3. To replace, reverse the process ensuring the water guard is at the bottom



If the rubber ring is removed, reattach with firm side facing out



Please note that the product design and specifications are subject to change without notice