

Uni

NECK READING LIGHT

— Operation Manual

enclize

Specification

Model	SE-Es04	Power	2W
Voltage	5V	Color Temperature	3000K/4000K/5000K

Important Safety Instructions

Note: Improper operation may cause damage to the product or property, and even serious injury to yourself and others. Before installing and using it, please pay attention to all instructions and warnings in the manual and understand local laws and related policies about this product.

Warning


- Do not put the product in an unstable place. Prevent the lamp from falling down and causing damage.
- The lamp is non-waterproof and non-moisture, and only suits for indoor dry occasions.
- Do not insert metals or flammables into the lamp, so as to avoid shortcut, electric shock and fire etc.
- Please ensure the specified rated voltage (5V). Long-term use under non-rated voltage conditions may cause the lamp to overheat and cause a fire.
- Please avoid direct sunlight to the lamp and keep it away from heating elements, otherwise it will cause the lamp to change color, damage or malfunction.

- Please wipe the product regularly with a dry cloth, and make sure disconnect the power supply in advance. Do not use liquid, spray cleaner or damp cloth for cleaning.
- Please do not unplug the Type-C cable in wet hands to prevent electric shock.
- The light source of the lamp is non-replaceable. When the light source reaches the end of its life, the entire lamp should be replaced.
- In case of any malfunction, please contact us for support. Do not disassemble the product by yourself.

In The Box



Neck Reading Light




Type-C Cable




User Manual

Functions



Accessory




Type-C Cable x1

Note:

- Please use the attached Type-C cable only.
- Please make sure the Type-C cable interface of the cable connected well with the lamp.

Note

Type-C Rechargeable Port



- Red Light** illuminates indicates charging.
- Green Light** illuminates indicates fully charged.

How to Use

ON / OFF

Short press A Switching or B Switching to turn on each light.
First turn on goes into warm white 10% brightness in default.

A Switching / B Switching Brightness Adjustment

Short press to adjust brightness from Low → Mid → High
Long press to gradually adjust the brightness from 10% ↔ 100%
*More than 30 seconds no touch the switch, a new short press will turn off the light.

Note:

A Switching can only control A Lamp
B Switching can only control B Lamp.

Color Temperature Switching

Short press to cycle through the color temperature: Warm White → Neutral White → Cool White

Maintenance

BEFORE CLEANING, MAKE SURE THE LAMP IS DISCONNECTED FROM THE ELECTRICAL SUPPLY.

- For the best usage to our product, please do repair and maintenance half a year.
- Turn off electricity, clean with dry cloth.

Shenzhen DiXuan Science&Technology Co., Ltd.
Address: Building B13, Hengfeng Industrial Park, Zhoushi Street,
Baoan, Shenzhen, China

Made in China