

PRODUCT MANUAL
HOME LUXURY SCENTS



HLS3500+

- Do not mix the fragrance with any other liquid
- Do not remove any piece or part of the diffuser
- This diffuser is only for use with our Scent Collection

Specification

Model	HLS3500+
Size	196.0*141.2*136.0mm
Weight	1.8kg
Power Adapter Input	220-240V~50/60Hz±5%
Power Adapter Output	5V±0.5V
Input	117±0.5%
Power	4.5W
Coverage	Super Coverage 180-360°
Life	0-1000h
Material	Plastic



Overview



How to install and use



- Press down to pop out the essential oil bottle.
- Rotate clockwise to secure the essential oil bottle and add essential oil.
- Align it with the correct position and press down to secure it in place.




- Press down to pop out the essential oil bottle.
- Rotate clockwise to secure the essential oil bottle and add essential oil.

Bluetooth instruction

Where to get the app:
Please visit "The HomeLux Scents" on Google play or App Store.

Note:
1. Please make sure you have Bluetooth function on your phone.
2. Please make sure you have the latest version of the app installed on your phone.



Amend password



If you forget the password, please press the reset button to return the factory setting. The factory setting password is 123456.

Concentration and Consumption

Pages	Work time(h)	Consumption	Consumption(g)
01	15	300	0.30
02	25	450	0.45
03	35	600	0.60
04	45	750	0.75
05	55	900	0.90
06	65	1050	1.05
07	75	1200	1.20
08	85	1350	1.35
09	95	1500	1.50
10	105	1650	1.65
11	115	1800	1.80
12	125	1950	1.95
13	135	2100	2.10
14	145	2250	2.25
15	155	2400	2.40
16	165	2550	2.55
17	175	2700	2.70
18	185	2850	2.85
19	195	3000	3.00
20	205	3150	3.15
21	215	3300	3.30
22	225	3450	3.45
23	235	3600	3.60
24	245	3750	3.75
25	255	3900	3.90
26	265	4050	4.05
27	275	4200	4.20
28	285	4350	4.35
29	295	4500	4.50
30	305	4650	4.65
31	315	4800	4.80
32	325	4950	4.95
33	335	5100	5.10
34	345	5250	5.25
35	355	5400	5.40
36	365	5550	5.55
37	375	5700	5.70
38	385	5850	5.85
39	395	6000	6.00
40	405	6150	6.15
41	415	6300	6.30
42	425	6450	6.45
43	435	6600	6.60
44	445	6750	6.75
45	455	6900	6.90
46	465	7050	7.05
47	475	7200	7.20
48	485	7350	7.35
49	495	7500	7.50
50	505	7650	7.65
51	515	7800	7.80
52	525	7950	7.95
53	535	8100	8.10
54	545	8250	8.25
55	555	8400	8.40
56	565	8550	8.55
57	575	8700	8.70
58	585	8850	8.85
59	595	9000	9.00
60	605	9150	9.15
61	615	9300	9.30
62	625	9450	9.45
63	635	9600	9.60
64	645	9750	9.75
65	655	9900	9.90
66	665	10050	10.05
67	675	10200	10.20
68	685	10350	10.35
69	695	10500	10.50
70	705	10650	10.65
71	715	10800	10.80
72	725	10950	10.95
73	735	11100	11.10
74	745	11250	11.25
75	755	11400	11.40
76	765	11550	11.55
77	775	11700	11.70
78	785	11850	11.85
79	795	12000	12.00
80	805	12150	12.15
81	815	12300	12.30
82	825	12450	12.45
83	835	12600	12.60
84	845	12750	12.75
85	855	12900	12.90
86	865	13050	13.05
87	875	13200	13.20
88	885	13350	13.35
89	895	13500	13.50
90	905	13650	13.65
91	915	13800	13.80
92	925	13950	13.95
93	935	14100	14.10
94	945	14250	14.25
95	955	14400	14.40
96	965	14550	14.55
97	975	14700	14.70
98	985	14850	14.85
99	995	15000	15.00
100	1005	15150	15.15

- Note:
1. The data shown above may obtained based on our testing result only.
2. The consumption rate will differ essential oil varies, the above data is only for reference, the actual data may vary.

Direction

Idea for MATHS/Conference rooms, MATHS, 334-335th Ave, Maple Valley, B.C. V2A 4P4. Available places at anywhere you want to experience experience.



Warning

1. Please read the user manual before operation & maintenance.

2. Make the machine vertical, laying flatness (avoid overflow).

3. Make sure the machine without essential oil inside the bottle before transportation.

4. Tighten oil bottle before use.

5. Clean the machine with alcohol every 1-2 months.

6. Do NOT modify, disassemble or repair the machine. If any failure occurs, please contact our technical personnel.

7. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

8. Children should be supervised to ensure that they do not play with the appliance.

9. The appliance is only to be used with the recommended operating medium. The use of other substances may generate a risk to fire risk.

Equipment cleaning

The machine needs to be cleaned when these conditions exist:

1. You're changing to another kind of essential oil.
2. The atomization volume becomes weak.

Cleaning steps:

1. Pull out the atomized head.
2. Fill a larger container and fill with industrial alcohol. Soak the atomized head and the tank for 5-10 mins.
3. Allow the atomizer head and the bottle to dry.

Caution

1. Do not modify, disassemble or repair the machine arbitrarily. Any failure happens, please contact technical staff.
2. Do not damage the power cord, force to bend, pull, twist, load, or fix equipment.
3. Do not use damaged plug or cord with the socket. Do not use over loaded power socket, wire or broken plug.
4. Do not touch the wire or product shell when the equipment is lighting.
5. Do not disassemble the machine when the power is opening.

Troubleshooting

Before asking to have the machine repaired, please try to diagnose the problem first by following the instructions below.

Problem	Solution
Does not start	Check whether the power cord is plugged in correctly. Check if the power switch is "On" (working position). Check whether the power cord is damaged. Check whether the power cord is plugged in correctly.
Does not work	The atomized head is blocked, clean with alcohol or change to a new atomized head. Check whether the power cord is plugged in correctly. Check whether the atomized head is connected.
Oil spill	Check whether the bottle is loose. Check if the pump is too damaged to be damaged. Try to fix it.
Oil spillage	The atomized head is damaged. Change to a new one. The atomized head is damaged. Change to a new one.
Atomized volume	The oil pump is damaged. Replace the pump. The oil pump is damaged. Replace the pump.

ISED Statement

English: This device contains license exempt (unlicensed) frequencies that comply with Innovation, Science and Economic Development Canada's license exempt (ISED) regulations. The device may not cause interference.
(1) This device may not cause interference.
(2) This device must accept any interference, including interference that may cause undesired operation of the device.
The digital apparatus complies with Canadian ICES-3 (B) (NRTL-3B).

French: Cet appareil contient des fréquences (non licenciées) exemptes de licence qui sont conformes aux RÈGLEMENTS du Service d'innovation, de science et de développement économique du Canada. L'appareil ne doit pas provoquer d'interférences.
(1) Cet appareil ne doit pas provoquer d'interférences.
(2) Cet appareil doit accepter toute interférence, y compris les interférences susceptibles de provoquer un fonctionnement indésirable de l'appareil.

L'appareil conforme aux normes canadiennes pour les appareils sans licence.

This device meets the exemption from the radio-frequency limits in section 2.3 of RSS-322 and complies with RSS-322 RF exposure limits. Users can obtain Canadian information on RF exposure and compliance.

Cet appareil est conforme à l'exemption des limites d'exposition radiofréquence dans la section 2.3 des RÈGLEMENTS sans licence. Les utilisateurs peuvent obtenir des données canadiennes sur l'exposition aux champs électromagnétiques.

This equipment complies with Canada's radiation exposure limits for use in an uncontrolled environment.
Cet équipement est conforme aux limites d'exposition aux rayonnements du Canada prévues pour un environnement non contrôlé.

This equipment should be installed and operated with minimum distance 10cm between the radiator and your body.
Cet équipement doit être installé et utilisé à une distance minimale de 10 cm entre le radiateur et votre corps.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to your television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into a different outlet, if available.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This disclaimer must not be considered as interfering in compliance with any other federal or international non-applicable.

RF Exposure

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 10cm between the radiator & your body.