

2-Way Video Monitor Model 1502B

Installation Instructions

1500 Series customer stations can be augmented with 2-way video capability. All video monitors are installed in the field. The 1502B is compatible with 1500A and 1500B.



MORE INFO

Mounting

- First connect the cable to the video port on the counter station.
- Then insert the two mounting screws into the rear and hand tighten.
- 1502B has a third mounting screw on the bottom. It is only used with 1500B counter stations. Do not attempt to drill a hole in a 1500A for this screw.

Digital Camera Tilt

The indoor camera view can be adjusted up or down digitally. This controls what the customer sees in the lane. Press the Mirror key, then Camera Up/Down.

Monitor Tilt Control

The monitor tilt can be hand adjusted. If the monitor does not hold position, use a hex wrench to tighten the mount as shown.

Monitor Height Position

The monitor height can be set to the low position by removing the four screws on the rear of the monitor and moving the bracket.



For more information visit:
<https://www.audioauthority.com/1502B>



Audio  Authority®

2048 Mercer Road, Lexington, KY 40511-1071 USA
800-322-8346 • 859-233-4599 • Fax: 859-233-4510
support@audioauthority.com • www.audioauthority.com

E-243 20250505