

尺寸: 70x105mm

MANUAL
GENERAL INSTRUCTIONS

Contents

WARRANTY	1
USE INSTRUCTIONS OF FLASHLIGHT	1-3
USE INSTRUCTIONS OF HEADLAMP	3-5
HOLDER INSTRUCTIONS OF FLASHLIGHT	5

FOR FLASHLIGHT

Dear valued customer, thank you very much for purchasing this product. Please properly read and understand this manual before using this product. The product will get hot in the strong light mode which is normal.

- Do not directly use the light directly with the flashlight to avoid eye irritation caused by strong light.
- Please charge when using for the first time or not using for a long time.
- Please install the battery into lens in correct direction to avoid any damage for flashlight. It every 3 months to take the battery in good condition.
- Please keep the battery skin intact during use. Damage battery skin may cause short circuit fire or explosion.

WARRANTY

- All the flashlights purchased from our company are under warranty. If you have any flashlight quality problem within one whole year after purchasing, please feel free to contact us anytime.
- The warranty time of battery and charger etc. is 3 months after purchasing.
- If your battery can't work for a very long time, please recharge and discharge it every 3 months to keep the battery in good condition.
- We won't accept any problems caused by any personal actions and unreasonable usage.
- If there's any quality problem, please send the product back with the warranty card.

INSTRUCTIONS FOR USE INSTRUCTIONS OF FLASHLIGHT

INSTRUCTIONS

- Using a USB cable plug into the USB interface of flashlight and connect

the other ends into USB charge phone charger or any other USB device. (As figure 1.1)




Figure 1.1 Power supply

- The indicator light should flickered when charging or battery low and turn to stable blue/green when fully charged. (As figure 1.2)



Figure 1.2 Charging ways

Some of the products could used as a power bank, you can charge you mobile phone. (As figure 1.3)



Figure 1.3 Power bank

INSTRUCTIONS FOR USE INSTRUCTIONS OF HEADLAMP

Different headlamps have different configurations and modes, please refer to the actual product.

- Product switch and modes switch:
 - Press the light switch to turn on the light, and continuously press the light to cycle between different modes. Long press 3-5s to turn off the lamp. Some lamps do not support long press to turn off.
 - Some light headlamps are designed with auxiliary lights, and long press the switch to light up.
 - Some lamps are designed for stepless dimming. Press and hold the button to continuously change the brightness of the lamp from strong to low or from low to strong, and release it to maintain the current brightness.
 - Some lamps are designed with a sensor switch. Press the sensor function switch to turn on the sensor function. Wave your hand in front of the lamp to control the switch of the lamp's bright light mode. Press the induction function switch again to turn off the sensor control function. (As figure 1.4)



Figure 1.5 Sensor function

- Product charging: Please use the USB cable for charging, and various standard USB interfaces such as mobile phone charging, can be used. The position of the charging interface is different for different models, and the rubber plug needs to be installed after charging. Note: different products have different configurations and modes, please refer to the actual product. (As figure 1.6)



Figure 1.6 Charging ways

- Rotating function: Some lamps have a rotating function, which can be achieved by pulling, pushing or rotating the lamp head. (As figure 1.7)



Figure 1.7 Rotating ways

- The size of the flashlight beam can be adjusted according to the situation, so that the lamp does not obviously, the lightness can be adjusted by yourself. (As figure 1.7)



Figure 1.7 Headlamp adjustment

INSTRUCTIONS FOR USE INSTRUCTIONS OF HEADLAMP

Remove the battery from the flashlight and place it in the charging unit. Please pay attention to the positive and negative poles of the battery. (As figure 1.8)



Figure 1.8 Battery positive and negative

Press the button at the Tail or Middle to turn On/Off the power, tap to adjust the modes and then press the light to cycle between different modes and long press 3-5s any mode to shut down. (As figure 1.9)




Figure 1.9 Light modes

Note: The lighting modes of different models of headlamps will be inconsistent, not limited to the above five lighting modes.

APPLICATION SHOWCASE



Figure 1.9 Light modes

WARRANTY CARD

Warranty card

User name: _____

Phone number: _____

E-mail: _____

Address: _____

Other Contacts: _____

Release Date: _____