

HB6233 英语说明书 (Hellobaby)

说明书为折叠式

尺寸：540*120MM

材质：100g双胶纸（彩色）


版本：V1.0

类型：环保

版本	修改内容	日期
Ver: 1.0	文件首发。	2022/02/21

设计	审核	审批
王勇		
2022/02/21		

540.00 mm



Thank you for purchasing the HB6233 Baby Monitor. With our baby monitor, you could see and hear your baby sleeping or playing in their room anytime.

Please retain your original dated sales receipt for your records. For warranty service of your product, you will need to provide a copy of your dated sales receipt to confirm warranty status. Registration is not required for warranty coverage.

PLEASE MAKE SURE THE FOLLOWING INCLUDED IN YOUR PACKAGE

Parent unit x 1	Camera unit x 1	Power Adapter x 2
User manual x 1	Wall-mounting kit x 1	

1. SAFETY INSTRUCTIONS

CAUTION: Keep the device away from children.

Strangulation Hazard: Children have STRANGLED in cords. Keep this cord out of the reach of children (more than 3ft (0.9m) away). Never use extension cords with AC Adapters. Only use the AC Adapters provided.

Choking Hazard: This product contains small parts, please be careful when unpack and assemble the product.

Head and keep to instructions: All the safety and operating in instructions should be read before the video baby monitor is operated. This product cannot replace responsible adult supervision.

Water and moisture: This product is designed for indoor use only. The unit should not be exposed to rain, moisture, dripping or splashing. No objects filled with liquid should be placed on top of, or beside the product, such as glass or vase. This item should not be used near water.

DO NOT: Use the appliance if the cord or plug is damaged. If your baby monitor is not operating properly or has suffered any damage, contact "Vediotest" service center to request inspection and repair of the appliance in order to avoid any possible risk.

DO NOT: Do not attempt to repair or adjust any of the electrical or mechanical functions of the unit. Otherwise, the guarantee will be made void.

Ventilation: This baby monitor should not be used on a bed, sofa, rug or similar surface that may block the ventilation openings, or be placed in an enclosed area such as a bookcase or drawer that may impede air flow.

Keep away from sources of heat: This unit should not be exposed to direct heat sources such as a candle, radiator, heat register, stove or other appliance that emits heat. The unit should not be left in direct sunlight.

Power source: This unit should only be used with the AC power adapters included in the package (Parent Unit: 100-240V AC 1A, Camera Unit: 5V DC 1A).

Damaged requiring service: This unit should be serviced by qualified personnel only when Objects have fallen or liquid has been spilled into the product;

The units have been exposed to rain.

The units do not appear to operate normally or exhibits a distinct change in performance;

- The units have been dropped or the enclosure damaged;

2. WARRANTY TERMS

We offer one year warranty from the original purchase date against defects in workmanship and materials. If you have warranty or support issues, please contact our after-sales service via email.

3. INSTALLATION GUIDELINES

- To use your parent unit and camera unit together, you have to establish a radio link between them, and the range will be affected by environmental conditions.
- * Any large metal object, like a refrigerator, a mirror, a filing cabinet, metallic doors or reinforced concrete between the baby and parent unit may block the radio signal.
- * The signal strength may also be reduced by other solid structures, like walls, or by radio or electronic equipment, such as TV, computers, cordless or mobile phones, fluorescent lights or dimmer switches.
- * Use of other 2.4GHz product, such as wireless network (Wi-Fi routers), Bluetooth systems, or microwave ovens, may cause interference with this product, so keep the baby monitor away at least 5ft (1.5m) from such products, or turn them off if they cause interference.

4. PLACEMENT OF THE BABY MONITOR

The camera can be placed on the desktop or mounted on the wall. Don't place baby monitor on soft quilted blankets or in the corners of cupboards, shelves, etc; Keep the baby monitor away from heat sources such as radiators, chimneys, cookers and direct sunlight; Keep the baby unit away from TV sets, microwave oven and radios. If interference occurs, move the camera to elsewhere;

* Place the camera within 6 feet (2 meters) of the area being monitored for optimum performance.



5. GETTING STARTED

5.1 TURN ON THE BABY UNIT:

- Insert the DC plug of the power adapter into the DC jack in the rear of the Baby Unit;
- Insert the other end of the power adapter into a suitable electrical outlet;
- Once the adapter is connected, the power LED will light up;

5.2 TURN ON THE PARENT UNIT:

- Insert the DC plug of the power adapter into the DC jack in the side of the parent Unit;
- Insert the other end of the power adapter into a suitable electrical outlet;
- Press and hold the power key 3 seconds on the top of the parent unit;
- Once parent unit is on, the power LED will light up and the image will display on the LCD



Note: Camera icon with "*" means it is well registered. You should select and pair with the camera icon without "*" sign.

8.1.1 ADD CAMERA

- Press the MENU key and the menu will pop up;
- Press the 4 key or 5 key until the camera icon is highlighted; then press 1 key or 2 key to select your desired camera;
- Press OK key to enter into sub-menu;
- Press 1 key or 2 key to select ADD CAMERA; then press OK key;
- When the icon is displayed on the LCD screen, press the PAIR button on the back of camera;
- Once paired, " appears on the LCD screen;
- If fails, repeat the above steps.

8.1.2 DELETE CAMERA

- Press the MENU key and the menu will pop up;
- Press the 4 key or 5 key until the camera icon is highlighted; then press 1 key or 2 key to select your desired camera;
- Press OK key to enter into sub-menu;
- Press 1 key or 2 key to select DEL CAMERA; then press OK key;
- Press 1 key to delete the camera;
- Press OK key to confirm the option.

8.2 VOLUME

- Press the 4 key and the menu bar will pop up;
- Press the 4 key or 5 key until the volume icon is highlighted;
- Press the 1 key or 2 key to select the desired volume level from level 1 ~ 5. (The default volume level setting is level 2 and level is OFF).

8.3 TEMPERATURE UNIT SETTING

- Press the 4 key and the menu bar will pop up;
- Press the 4 key or 5 key until the temperature icon is highlighted;
- Press 1 key or 2 key to select between "F" or "C";
- Press OK key to confirm;
- Press the key to exit.

Note: The default temperature range is 0~50 °C.

8.3.1 TEMPERATURE ALARM SETTING

- Press 1 key or 2 key to select "On" for alarm setting;
- Press 1 key or 2 key to select "Off" for confirming alarm on "On" then followed by "C" for switching off alarm function.

8.3.2 SET TEMPERATURE HIGH ALERT LIMITS

- When "On" is highlighted at alarm setting then press 1 key to enter Hi/Li limits setting.
- Press 1 key or 2 key to select the Hi/Li limit then press "C" to confirm.
- Press the cursor will jump to Li limit setting.

4. Press 1 key or 2 key to adjust the Lo limit then press "C" to confirm.

5. Press the 4 key or 5 key until the setting icon is highlighted; then press 1 key or 2 key to select the setting icon.

Note: The high temperature alarm range is 20~40 °C, and the Low temperature alarm range is 0~19 °C. The high temperature alarm default setting is 36 °C, and the low temperature alarm default setting is 8 °C. When the temperature goes above or below the setting, the temperature icon turns red. It will flash to alert user by audio beep. Press any key on the parent unit to stop beeping and flashing.

8.4 SLEEPER SETTING

You can soothe the baby to sleep by playing a gentle lullaby from the Camera unit.

- Press the MENU key and the menu will pop up;
- Press the 4 key or 5 key until the lullaby icon is highlighted;
- Press 1 key or 2 key to select one of the 8 available lullabies; you can pick single playback, loop (all lullabies) playback or stop;
- Press OK key to confirm.

Note: The lullaby default setting is OFF.

8.5 ALARM SETTING

You can use the Parent Unit to set an alarm as a reminder for you to take care of your baby. If an alarm time is selected, the Parent Unit will beep at the end of the selected hour period from 30min to 6hrs with 30min step interval. The alarm will sound for about 1 minute when the time is reached, or can be stopped by pressing any key.

- Press the MENU key and the menu will pop up;
- Press the 4 key or 5 key until the alarm icon is highlighted;
- Press the 1 key or 2 key to select the expected times.
- Press OK key to confirm.

Note: The alarm default setting is OFF. When the alarm is ringing, press any key on the parent unit to stop.

8.6 DISPLAY BRIGHTNESS

- Press the 4 key and the menu bar will pop up;
- Press the 4 key or 5 key until the brightness icon is highlighted;
- Press 1 key or 2 key to select the desired brightness level from level 1 ~ 5. (The default brightness level setting is level 3.)

8.7 VOX SETTING

This mode allows you to control the sound activation of your baby unit. If there is no sound around the baby unit within 30 seconds, it will stop audio transmission and turn off the screen of the parent unit. When the baby detects any sounds louder than the sensitivity level, it will start transmitting the signal to the parent unit again and turn on the screen of the parent unit. To change the VOX level, please follow the below instructions.

- Press 1 key and the menu bar will pop up;
- Press 1 key or 2 key to select the VOX level;
- Press 1 key or 2 key to select the VOX sensitivity level.
- Press OK key to confirm setting.

Frequency	2403.5MHz~2475.5MHz
Parent Unit: 100-240VAC 50/60Hz	
Output: 5V DC 1A	
Camera Unit: 100-240VAC 50/60Hz	
Output: 5V DC 1A	
Operating Range	Up to 1000ft (300m) outdoor (line of sight) Up to 165ft (50m) indoor
Display	3.2" Diagonal TFT LCD
Battery (Parent Unit)	Li-ion 2.7V 950mAh (3.525Wh)
Battery life	Up to 8 hours
Maximum power	< 1900mW
Operation environment	Operating Temperature: +32F~+104F (0°C~40°C) Battery Charging Temperature: +59F~+104F (15°C~40°C) Relative Humidity: 15%~85%

11. MAINTENANCE

- Clean your baby monitor with a slightly damp or anti-static cloth.
- Never use cleaning agents or solvents.

12. DISPOSAL GUIDE FOR BATTERY AND PRODUCT

Do not attempt to repair or adjust any of the electrical or mechanical functions of the unit.

* Remember to dispose of the product in an environmentally responsible way.

* For proper collection and processing of these products, take them to the collection points designated by local authorities. You can also contact the store where you purchased the product.

Improper or incorrect use of batteries may cause corrosion or battery leakage, which could cause personal injury or damage to property. Use only the types of the batteries which are indicated in this manual.

CAUTION: Risk of Fire and Burns. Do Not Open, Crush, Heat Above 45 degree C or Incinerate. Follow Manufacturer's Instructions.

* Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, can result in an explosion;

* Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas;

* A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas;

* The battery shall not be exposed to excessive heat such as sunshine, fire or the like;

FCC/CE/ISED Statement

This device complies with Part 15 of the FCC Rules and with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Cet appareil est conforme à la partie 15 des règles de la FCC et aux normes RSS exemptées de licence d'Industrie Canada. Le fonctionnement est soumis aux conditions suivantes: (1) l'appareil ne doit pas causer d'interférences nuisables, et (2) cet appareil doit accepter toute interférence reçue, y compris les interférences pouvant entraîner un fonctionnement indésirable.

Notes or modifications to this test not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

WARNING: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS 102. If exposure, users can obtain Canadian information on RF exposure and compliance.

Cet appareil est conforme à l'exemption des limites d'évaluation courantes dans la section 2.5 du C. 102 et conforme avec RSS 102 de l'exposition aux RF. Les utilisateurs peuvent obtenir des données canadiennes sur l'exposition aux champs RF et la conformité.

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment.

Cet équipement est conforme aux limites d'exposition aux rayonnements du Canada établies pour un environnement non contrôlé.

Radiation Exposure Statement for camera

This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Cet équipement doit être installé et utilisé à une distance minimale de 20 cm entre le radiateur et votre corps.

Specific Absorption Rate (SAR) Information:

This Monitor meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. ISED RF Exposure Information and Statement the SAR limit of Canada (ISED) is 1.6 W/kg averaged over one gram of tissue. Device types: Monitor has also been tested against this SAR limit. This device was tested for typical body-worn operations with the back of the Monitor kept firm from the body. To maintain compliance with ISED RF exposure requirements, use accessories that maintain an 10mm separation distance between the user's body and the back of the Monitor. The use of bulk clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with ISED RF exposure requirements, and should be avoided.

Information sur le débit d'absorption spécifique (DAS):

Cette caméra répond aux exigences du gouvernement en matière d'exposition au champ radio. Les lignes directrices sont basées sur des normes élaborées par des organisations scientifiques indépendantes à travers une évaluation périodique et approfondie des études scientifiques. Les normes comprennent une marge de sécurité substantielle conçue pour assurer la sécurité de toutes les personnes, quel que soit leur âge ou leur état de santé. Information et déclaration d'ISED sur l'exposition aux RF le limite DAS du Canada (ISED) est

de 1,6 W/kg en moyenne sur un gramme de tissu. Types d'appareils: la Moniteur a également été testée par rapport à cette limite SAR. Cet appareil a été testé pour des opérations typiques portées sur le corps avec le dos de la Moniteur gardé à 10 mm du corps. Pour maintenir la conformité avec les exigences d'exposition RF d'ISED, utilisez des accessoires qui maintiennent une distance de séparation de 10 mm entre le corps de l'utilisateur et l'arrière de la Moniteur. L'utilisation de clips de ceinture, d'étuis et d'accessoires similaires ne doit pas contenir de composants métalliques dans son assemblage. L'utilisation d'accessoires qui ne satisfont pas à ces exigences peut ne pas être conforme aux exigences d'exposition aux RF d'ISED ou de leur évalue.

EU Declaration of Conformity (DOC)

Hereby, Vediotest declares that the radio equipment type is in compliance with RED Directive 2014/53/EU.

The full text of the EU declaration of conformity is available on the website: www.hellobaby.net.cn

Model: HB6233

Responsible Party(S): Startline LLC

Addr: 22 Hardsell Drive, Jericho, NY 11753 Tel: 1-516-681-3729

Authorized UK Representative (UK): Safelure wnt Ltd

Addr: 10 Progress road, High Wycombe, Bucks HP12 3JF Tel: +44(0)74075702799

Shenzhen Vediotest Technology Co., Ltd

701, Building 3, No. 1, Zhenhan Road, Ganfeng Community, Jihua Street Office, Longgang District, Shenzhen

WARNING: IR emitted from this product. Do not stare at operating lamp

Product tested against EN62471