




Insert the connector boot onto the cable



Strip outer jacket about 50mm to reveal 900-micron fibers




Using the label, measure from the end of the buffer and make a mark between the 250 $\mu$ m and 125 $\mu$ m section




Strip the buffer to the mark using the middle hole, then the small hole on the stripper in short increments



Cleave your fiber strand to 10mm from the mark



Strip the remaining 20mm of buffer using the middle hole on the stripper




Clean any impurities from your cable using alcohol and a lint-free cloth



Insert the fiber into the connector body until the strand meets resistance and bows slightly



Remove the connector jig



Lock the fiber inside the connector by pressing the amber button



Screw the boot onto the connector body and trim any exposed Kevlar yarn



To remove or re-terminate the connector, simply unscrew the boot and replace the jig