

Congratulations on your purchase!









ALWAYS wear a helmet when riding your electric scooter.



Make sure your scooter has a full battery before taking it out to ride.



Always be aware of local road laws, and follow them.



Do not ride the scooter under the influence of drugs or alcohol.



Always respect pedestrians.



Do not ride under wet conditions. The scooter may slide from under your feet causing injury. Wet conditions may damage the electronics and void the warranty.




Warning Message

- Avoid water The scooter is not waterproof. The electronics may be damaged due
 to water and water damage is not covered by our warranty. Riding in wet conditions
 is also very dangerous and may result in injury.
- Abuse We do not cover physical damage due to negligent care and extreme riding.
- 3. Whenever you ride the GOTRAX scooter, you risk severe injury or even death from loss of control, collisions, and falls. Use caution and ride at your own risk.
- 4. **Do not** modify the product from the manufacturer's original design.
- Keep hands and all body parts away from moving parts while operating the scooter.
- Before riding be sure to check the scooter over and make sure the scooter is operating correctly before each use.
- 7. Before riding be sure to check that the braking system is functioning properly; also be sure to check that all safety labels are in place and you understand the safety warnings.
- 8. **Before riding** be sure that any and all axle guards, chain guards, or other covers or guards supplied by the manufacturer are in place and in serviceable condition.
- Before riding be sure to check that the tires are in good condition, inflated properly, and have sufficient tread remaining.
- 10. Never exceed the 220 lb (100 kg) maximum load rating.
- 11. The electric scooter should **never** be used by children under the age of 16.
- 12. Maximum Speed Your electric scooter goes the maximum speed of 20 mph.



You should find each of these items in your box:


- 1. Electric Scooter
- 2. 4 Screws
- 3. 3mm Allen Wrench
- 4. Approved Power Adapter / Charging Unit
- 5. Tire pump extender



Remove all packaging material, then inspect each item for any accidental damage that may have occurred during shipping.



Get To Know Your Scooter



Specifications

Top Speed: 20 mph Distance per Charge: 21-25 Miles Weight Range Up To: 220lbs **Battery Type:** 36V 10.4AH DC 42V 2.0A **Battery Charger:** 3-4 hours Charge Time:

AC 100-240V~50/60HZ 3.0A Power Requirements:



Assemble Your Scooter



Straighten the tiller and lift the tiller upright (as shown in the figure).




Press the folding lever as the figure shows to lock the tiller.



Insert the exposed cable into tiller and then insert the console into the tiller. Use the tool and screws to lock the console into place (as shown in the figure).



Before using the scooter, you must fully charge the battery.



- 1. Open the rubber charging port cover.
- 2. Insert the charging plug into the port.
- The charger box will have a green light when fully charged and a red light when charging.
- When you are done charging be sure cover the charging port to keep it clear of dust and debris.
- 5. Charging Time: 4.5 hours

Charging Requirement: Make sure to charge your scooter in conditions that do not exceed 104 degrees Fahrenheit or below 32 degrees Fahrenheit.



Long press power button to power on and off.

Hold "+" button for 3 seconds to power the headlight and tail light power on and off.

To unlock the display lock the password is 000. Use the " + " button to input 0 and press the power button to set. Repeat the process to enter in the full code 000. Once all three zero's have been selected, press the power button twice to deactivate the lock.

To set your own code, press the " + " button and the power button together for 10 seconds. Then use the " + " button to input the first number of your code and press the power button to set. Repeat the process to set your own individual three number code. Once your three number code is selected, press the power button twice to deactivate the lock.

Press the throttle for 8 seconds to activate **Cruise Control** while moving. Press the handbrake to cancel the cruise control feature.

Hold the "-" button while walking next to the scooter to activate push assist mode. Once the push assist mode has been activated the scooter will move at 1.8 mph to make it easier to walk next to the scooter.

The console on the scooter displays speed in MPH, Distance, Battery life, and the Headlights.

To lock the tiller lock, adjust the password wheel to show "0000". Pull the lock pin and insert it into the lock hole. Scramble the password wheel to lock.

To unlock the tiller lock, adjust the password wheel to show "0000". Press the button and pull out the lock pin from the lock hole and insert the lock pin cord back into the tiller.

To set your own code, Adjust the password wheel to show "0000" and then push the set button to the "set" position. Adjust the password wheel to the four digit code of your choice and then push the set button back to the left.




- You will want to start riding your scooter with one foot on the platform and one foot on the ground. Use your foot on the ground to push off and at the same time, press the throttle button to begin movement.
- 2. Press the brake handbrake to slow down or stop.
- 3. The scooters perform best when on a smooth surface e.g. carparks, smooth roads, footpaths, & bike lanes.
- Always clean your scooter (wheels, platform, etc.), it's a machine and it needs to be maintained.
- 5. Do not press the throttle while walking with the scooter beside you.
- 6. Be aware of the terrain you are riding on, watch out for curbs and obstacles!

Putting Your Scooter Away/Folding

Before folding the scooter, make sure that the scooter is powered off. .

Folding: Ensure the electric scooter is powered off, press the lock buckle as the figure shows and pull down the lever. Fold the tiller down towards the rear fender and lock the tiller hook to the fender hook buckle.

Unfolding: Disconnect the tiller hook from the fender hook. Once unhooked pull the tiller upwards and lock the locking device on the bottom of the tiller by pulling the clamp towards the tiller. Make sure to test the tiller before riding to make sure it is locked into place.



X Maintenance & Repair

If you regularly clean and maintain your electric scooter, it will extend its life.

Cleaning and storage: If the scooter is dirty, wipe it clean with a soft damp cloth.

Disc Brake Adjustments: If the brake is too tight, use a 4mm Allen wrench to loosen the screws counterclockwise. Push the brake wire to shorten and lock the screw in place. If the brake is too loose, loosen the screws and pull the brake wire to extend the wire and lock the screws.

Tiller Adjustments: If the tiller wiggles while riding, please check the folding mechanism. Use an Allen wrench to tighten the screws as the figure shows.

Tires: If you notice that the tire pressure is low, please fill to the recommended PSI on the side of the tire. Recommended PSI: 50

DO NOT use alcohol, gasoline, kerosene, or other corrosive chemical solvents to clean the scooter. It can severely damage the appearance and structure of the scooter. Please do not use a pressure washer as it may also cause damage to the electronics.

Storage: When you're not using your scooter store in a dry and cool location. Avoid storing your scooter outdoors because sun exposure can damage it's appearance and may cause wear on the life of the battery and tires.



Only use the approved GOTRAX power adapter to charge your scooter, others may cause risk of fire & equipment may be damaged.

Improper disposal of used batteries may seriously pollute the environment. Please comply with local disposal regulations.

Make sure to store your scooter and power adapter in conditions that do not exceed 122 degrees Fahrenheit or below -4 degrees.

Warning - Risk of Fire - No User Serviceable Parts, The prolonged exposure to UV Rays, Rain and the Elements may damage the enclosed materials, store indoors when not in use.

X Troubleshooting

We frequently update our user manuals at **GOTRAX.com**, and reserve the rights to update and change manuals online.

Please contact our customer service team if you are experiencing problems or need more detailed information. They can be reached at GOTRAX.com



For warranty information, please visit GOTRAX.com.



WWW.GOTRAX.COM

#RideGOTRAX





GOLABS, INC

GOTRAX.com 2201 Luna Rd. Carrollton, TX 75006