



SDX-1000 Wiring Connections



SDX-1000 CONNECTIONS

Ethernet							
T-568A				T-568B			
1	2	3	4	5	6	7	8
Green/White	Green	Orange/White	Blue	Blue/White	Orange	Brown/White	Brown
1	2	3	4	5	6	7	8
Orange/White	Orange	Green/White	Blue	Blue/White	Green	Brown/White	Brown



INSTRUCTIONS TO INSTALLER:

1. Use a standard RJ-45 Ethernet connection (T-568A or T-568B) and CAT-5e cable or higher.
 2. Connect the Ethernet cable on one end to the SDX- 1000 and the other end to a standalone Ethernet network switch. Make sure both ends of the cable are manufactured using either the T-568A or T-568B standard a shown above.
 3. Connect power using the provided 12VDC power adapter.
- i** Both ends of cable must follow the same standard.
- i** SDX-1000 must be on an stand alone Ethernet network. Do not install on a network that is exposed to non Ebtron approved devices, including the B.A.S.
- i** USB port is used for system and application updates, and certain SDX-1000 features.