

Type-C receiver


**User Manual**



Thanks for choosing our product.

This product is a smart wireless microphone that provides professional-grade recording output. Plug and play, no app required. Multiple uses: It can be used in online live broadcast, video Vlog shooting, program interview, recording, video teaching and other occasions.

The wireless Microphone consists of two parts, one is Microphone transmitter , the other one is Type-C receiver. (See as below picture)



① Windproof net

② Microphone indicator

③ Microphone Type-C charging port

④ Microphone clip

⑤ Switch key

⑥ Microphone reset key

⑦ Type-C port to connect phone

⑧ Receiver indicator

⑨ Reset key of receiver

\*\*\*\*\*Some Android phones may have incompatibility problems due to system , please consult your dealer for details\*\*\*\*\*

Step 1: Connect the Type-C receiver to phone with Type-C port. The connection is successful if the phone displays a small icon.




Diagram of a mobile phone with a switch key. The phone is shown from the back, with a switch key located at the bottom. A label "Switch key" points to the switch key.

Indicator red light always on

Note: Some models do not have this function, and the real object shall prevail

Microphone Transmitter		
Function	How to use	Light
Power on	Press switch key once	Green light on
Power off	Press switch key about 3 seconds	Light off
Pairing		Red and green flash alternately
Paired		Green light keeps on
Pause	Press switch key once	The green light flashes slowly during pause
Reset	Press reset key for 3 seconds	
Low battery alarm	<b>Power on state</b>	The red and green lights come on every 10 seconds
Charging	Charging with Type-C cable	The red light goes out when it is fully charged

Function	How to use	Light
Power on	Plug in the device	Red light on
Power off	Plug off the device	Light off
Pairing		Red light flashes slowly
Paired		Red light on

**Content of packing**

- (1) Microphone transmitter
- (2) Type-C receiver
- (3) Type-C charging cable
- (4) User manual