@ Dismantling Instructions

LED (6500 K + UV) Magnifier Lamp

Item no: 3030237

1 Dismantling recommendations

- Disconnect from power supply.
- Ask help from a professional if needed.

2 Dismantling instructions

Step 1

Product overview.

Pull out the lamp cover.



Step 2
Use the screwdriver to remove the screws from the metal connector. Take out the knob, use the soldering to desolder the wire and separate the light source with the arm.



Step 3
Pull out the wire from the arm and desolder the PCB in the lamp head.



Step 4
Test the light source.



This is a publication by Conrad Electronic SE, Klaus-Conrad-Str. 1, D-92240 Hirschau (www.conrad.com).

All rights including translation reserved. Reproduction by any method (e.g. photocopying, microfilming or the capture in electronic data processing systems) requires prior written approval from the editor. Reprinting, also in part, is prohibited. This publication reflects the technical status at the time of printing.

Copyright by Conrad Electronic SE.

*3030237_V1_0524_hs_en 1396633099 I1/O1 en