



Press position	Function
ON/OFF	ON/OFF
LIGHT+	In M1 Mode: brightness +; In M2/M3 Mode: brightness +; In M4/M5 Mode: brightness +; change mode speed
LIGHT-	In M1 Mode: brightness -; In M2/M3 Mode: brightness -; In M4/M5 Mode: brightness -; change mode speed
3H (Timer)	Turn on for 3 hours, turn off for 24 hours
6H (Timer)	Turn on for 6 hours, turn off for 18 hours
AUTO	Timer OFF
M1	Always On
M2	Slow Flash
M3	Fast Flash
M4	Jumping Flash
M5	Breathing

#### Remote Pairing Instruction:

- ① After the adapter is powered on, press and hold the ON/OFF button for 30 seconds until the light turns off, then the matching is successful, and then press the ON button to turn it on. One remote control can also control multiple products at the same time. You only need to power on these products at least 30 seconds at the same time and repeat the above steps to achieve this.
- ② In Steady mode, the +- button adjusts the brightness.
- ③ In Breath/Flash mode, the +- button adjusts the breathing flash mode speed.

Operating voltage: DC3V ( 1.5V\*2 AAA button battery)

Operating current: less than 20MA when transmitting

Operating frequency: 433.92MHZ

Modulation mode: OOK

Standby current: less than 5UA

Size: 98\*40.5\*11mm

Product quality: 24.5g

#### FCC warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful

interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.