

## **DTAV40E2 Series**

## **Setting The Time of Day:**

Follow this procedure to set the time of day and day of the week.

- **1.** Press and release the **Reset** button with a blunt object to reset the unit. The timer screen flashes.
- **2.** Press and hold  $\Theta$  and **h+** simultaneously to access the **12:00 AM** screen.
- 3. Take one of these actions.

If	Then
Your time zone currently is in Daylight Savings Time,	Press the +1h button. Go to step 4.
Your time zone is not in Daylight Savings Time	Go to step 4 to set the current time.

- **4.** Press and hold  $\Theta$  and press **h+** repeatedly until you advance to the current hour.
- **5.** Press and hold  $\Theta$  and press  $\mathbf{m}$ + repeatedly until you advance to the current minute.
- **6.** Press and hold  $\Theta$  and press **Day** repeatedly until you advance to the current day.

## **Programming Events**

To set ON/OFF event pair, set ON event and then repeat procedure to set OFF event. The timer enables up to 7 ON/OFF event pairs.

 Press the **Timer** button. Dashed lines appear to indicate no event is set for event 1.

Press Day to select the days of the week for the ON event. NOTE: To set the ON event:

INIO TO	VVE	ΙП	FK	SA	50
ON	-	- ;	-	-	•

ON a Specific Day	Select: The desired day
Every Day of Week	Select: MO, TU, WE, TH, FR, SA, SU
Every Weekday:	Select: MO, TU, WE, TH, FR
Every Weekend:	Select: <b>SA, SU</b>
Monday through Saturday	Select: MO through SAT
Monday, Wednesday, Friday	Select: MO, WE, FR

- 3. Press **h+** to scroll to the desired hour for ON event.
- **4.** Press **m+** to scroll to the desired minute for the ON event.
- **5.** Press **Timer** to advance to the OFF event screen.
- **6.** Press **Day** to select the days of the week for the OFF event.
- 7. Press **h+** to scroll to the desired hour for the OFF event.
- **8.** Press m+ to scroll to the desired minute for the OFF event.

Take one of these actions.

If	Then			
You need to program another ON/OFF event pair,	Press Timer to advance to the next event ON screen and repeat steps 2 through 8.			
All the required ON/OFF events are programmed,	Press to return main screen. The procedure is complete.			

**NOTE:** If events include or intersect with each other, each ON/OFF event can be independently executed at the setpoint. **NOTE:** If an ON event and OFF event occur at the same time, the timer will run the OFF event.