


# Wireless Microphone

User Manual




## Introduction

Thanks for choosing our product.  
This product is a smart wireless microphone that provides professional-grade recording output. Plug and play, no app required. Multiple uses: It can be used in online live broadcast, video Vlog shooting, program interview, recording, video teaching and other occasions.  
The wireless Microphone consists of two parts, one is Microphone transmitter, the other one is receiver. (See as below picture)




## ID Diagram



- ① Windproof net
  - ② Microphone indicator
  - ③ Microphone charging port
  - ④ Microphone clip
  - ⑤ Switch key
  - ⑥ port to connect phone
  - ⑦ Receiver indicator
  - ⑧ port of receiver
- \*The function of above ⑥ will be specifically explained later.  
\*\*\*\*\*Some Android phones may have incompatibility problems due to system, please consult your dealer for details\*\*\*\*\*


## How to use

Step 1: Connect the receiver to phone with port.




Note: oppo / vivo / iqoo / realm brand mobile phones can be used normally only when they go to the settings (search "OTG" - turn on OTG power supply)


Step 2: Press switch key of microphone, the indicator light turns green, and then power is turned on.



Step 3: The indicator light of receiver keeps always on, then open the phone camera, live App or other Apps, and then to use the microphone to receive sound.



Special Note:  
For the use of ⑧ port: there is no battery in receiver, and no need to recharge during live. If the phone is low power during live, it can be recharged directly through ⑧ port.



## About UI

### Microphone Transmitter

Function	How to use	Light
Power on	Press switch key once	Green light on
Power off	Press switch key about 3 seconds	Light off
Pairing		Red and green flash alternately
Paired		Green light keeps on
Pause /Recovery	Press switch key once	The green light flashes slowly during pause
Low battery alarm	Power on state	The red and green lights come on every 10 seconds
Charging	Charging with cable	The red light goes out when it is fully charged

### Receiver

Function	How to use	Light
Power on	Plug in the device	light on
Power off	Plug off the device	Light off
Pairing		light, slow
Paired		The light's

REVERB MODE: Press the START BUTTON 2 times continuously to enter reverb mode  
Product support and listening function  
This product comes with AI noise reduction, which will enter the noise reduction mode when it is started

## Packing List

### Content of packing

- (1) Microphone transmitter
- (2) receiver
- (3) charging cable
- (4) User manual

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.