


INSTALLATION INSTRUCTION

9PRSBQ, 9PRSTQ, 9PRSTQX Steel Quick Lock Rear Ladder Rack



Fitting Time: 0 Hours: 30 Minutes





Installation of this accessory requires the use of power tools. Check that all work practices comply with safety standards, wear appropriate clothing and use personal protection equipment.









Please read these instructions carefully before installation, paying special attention to all Notice, Caution & Warning notes. Failure to do so may result in damaged parts or injury to the installer or customer.

Issue 1: 26/06/2024 Document No.: 9PRSBQ-FI Page 1 of 5



INSTALLATION INSTRUCTION

Steel Quick Lock Rear Ladder Rack

Kit Contents

NOTE: CHECK KIT CONTENTS BEFORE COMMENCING FITMENT AND REPORT ANY DISCREPANCIES

Item	Description	Qty
1	Ladder Rack	1
2	Quick Lock Ladder Rack Socket LH	1
3	Quick Lock Ladder Rack Socket RH	1
4	Quick Lock Socket Plate	2
5	Quick Lock Ladder Rack Base Plate	2
6	Ladder Rack Socket Plate	2
7	Quick Lock Rack Key	2
8	M6 Twin Nutplate	2
10	M12 Nyloc Nut	6
11	M10 Nyloc Nut	4
12	M6 Nyloc Nut	8
13	M12x50 Hex Bolt	2
14	M12x40 Hex Bolt	4
15	M10x35 Button Head Cap Screw	4
16	M6x25 Hex Bolt	4
17	M6x20 Hex Bolt	8
18	3/8 x 3/4 x16G Flat Washer	4
19	M12x25x5 Flat Washer	2
20	M6 Spring Washer	4
21	Spring	2

|--|

	Lad	Item	Description	Qty
Pin	der	9	Ladder Rack Washer	2
Rack Ear (Tube)	22	M8x180 Coach Bolt	2	
	23	Tube Ladder Rack Ear Pin	2	
	Ear	24	M8 Nyloc Nut	2

Fo		Item	Description	Qty
ars (J pl	25	Fold Down Ear	4
Bo	VOC	26	M8x65 Hex Bolt	4
≥ ≦	'n	27	M8 Nyloc Nut	4

	٦f	Item	Description	Qty
_	old	9	Ladder Rack Washer	2
Tube	Down	27	M8 Nyloc Nut	4
wn Ears be)		25	Fold Down Ear	4
	Ear	29	M8x90 Hex Bolt	4
	S	30	M8 Washer	8

Tools Required

TOOLS REQUIRED			
Ratchet			
10mm Socket	10mm Spanner		
13mm Socket	13mm Spanner		
17mm Spanner	6mm Hex Key		
19mm Socket	19mm Spanner		
Tape Measure	13mm Drill Bit		
Cordless Drill	Marker		

Fastener Torque Table

Fastener size	Class	Torque	
M6	8.8	9 Nm	
M8	8.8	23 Nm	
M12	8.8	79 Nm	

Issue 1: 25/06/2024 Page 2 of 5



INSTALLATION INSTRUCTIONSteel Quick Lock Rear Ladder Rack


SECTION 1 - Ear Installation

STEP 1a

Note: Step 1a is for Tube Racks with Pin Ears.

Insert the Tube Ladder Rack Ear into the round tube ladder and headboard and fasten with an M8 galvanized nut.

Go to Step 2.




STEP 1b

Note: Step 1b is for Bow Racks with Fold Down Ears.

Fasten the fold down Ear Tube Ladder Rack Ear to the square tube ladder rack and headboard using the supplied M8x65 Bolts and nyloc nuts. Ensure fasteners are not overtightened, as to inhibit the folding movement of the ears.

Go to Step 2.




STEP 1c

Note: Step 1c is for Tube Racks with Fold Down Ears.

Fasten the fold down Ear Tube Ladder Rack Ear to the tube ladder rack and headboard using the supplied M8x90 Bolts and nyloc nuts.
Ensure fasteners are not overtightened, as to inhibit the folding movement of the ears.

Go to Step 2.



Issue 1: 25/06/2024 Page 3 of 5



INSTALLATION INSTRUCTION

Steel Quick Lock Rear Ladder Rack


SECTION 2 - Rack Installation

STEP 2

Remove the taptite screw located in the rearmost corner of the tray deck.

Remove the 2 black plugs in the rear of the coaming.

Repeat for both left and right hand sides.




STEP 3

Position Base Plate bracket against coaming and steel deck and align with holes in coaming.

Using Base Plate as a template, mark holes on deck & drill using 13mm drill.

Position M6 nutplate from inside the coaming cavity and install M6x25 bolts & M6 spring washers through bracket and coaming to the M6 nutplate.


Install M12x40 bolts through bracket and deck. Install Ladder Rack socket plate from underneath deck to rear most hole and fasten with M12 Nyloc nut.



STEP 4

Install Quick Lock Rack Key to the Base Plate using M6x20 bolts and M6 Nyloc nuts.

Ensure the top faces of the QL Rack Key and the Base Plate are flash. See inset image.



Issue 1: 25/06/2024 Page 4 of 5




INSTALLATION INSTRUCTION Steel Quick Lock Rear Ladder Rack

STEP 5

Install Ladder Rack Sockets to the Ladder Rack using M10x35 Button Head Cap screws and 3/8x3/4x16G washers, and fasten to inside of steel tube using a curved ladder rack washer and M10 nyloc nuts as per adjacent diagram.






STEP 6

Loosely install Quick Lock Socket Plate to the Ladder Rack Socket by using M12x50 bolt, M12x25x5 Washer, Spring and M12 Nyloc Nut as per adjacent diagram.

Note: Only hand tighten at this stage.




STEP 7

Position Ladder Rack over the Base Plate and apply pressure inward to allow the Quick Lock Tube Socket to fit over the Quick Lock Rack Key.

Then apply pressure downward to mate the Quick Lock Tube Socket to the Quick Lock Rack Key.

Tighten the M12 bolt to secure the Ladder Rack to the Base plate.



Issue 1: 25/06/2024 Page 5 of 5