



## MAXHUB SN03 ePaper SmartNote User Manual

[Home](#) » [MAXHUB](#) » MAXHUB SN03 ePaper SmartNote User Manual 

# MAXHUB



All pictures in this manual are for reference only, please refer to the actual product.

## Contents

- 1 Safety Warnings
- 2 Statement
- 3 FCC Caution:
- 4 Accessories
- 5 Precautions For First Use
- 6 Appearance Introduction
- 7 Instructions For Use
- 8 Documents / Resources
  - 8.1 References

## Safety Warnings

Before using and operating this equipment, please read and observe the following precautions carefully to avoid dangerous or illegal operations.

### • Placement

- ① Do Not charge or use this product in a dusty or humid place, so as not to cause internal circuit failure of the product.
- ② Do Not place this product near heating objects such as electric heaters.
- ③ Normal operating temperature is 0-40°C, normal operating humidity is 10-90%RH.

### • Children Safety

- ① This product and accessories may contain some small parts, please do not place them where children can reach to avoid danger.

### • Power Supply

- ① Please use the standard cable of this product.
- ② Please use a 5V 1.5A charger for charging.
- ③ Short press the power button to enter sleep mode, and long press the power button to enter shutdown mode.

### • Water Precaution

- ① The product is not waterproof, Please keep it dry.

### • Maintenance

- ① Anti-glare film is used on the surface of the screen, please protect it to prevent scratches.
- ② Please contact professional service personnel for maintenance services.
- ③ When the equipment is damaged, please do not disassemble it for repair without permission, please call customer service to report for repair.
- ④ Do Not insert any sharp or pointed object into the device.
- ⑤ Do Not drop or hit the device to avoid damage to the device.

## Statement

1. Intellectual property right statement: The hardware design and software of this product are covered by the patents. Anyone who reproduces this product or the content of the instruction without the authorization of the

Company shall assume legal liabilities.

2. This manual is for reference only, and the actual function of the final product is subject to the actual function of the product received by the customer.
3. The picture is for reference only, please refer to the actual product. The company reserves the right to improve and change the appearance and design of the product without notice.

### **FCC Caution:**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### **Federal Communication Commission Interference Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### **Non-modification Statement:**

**Caution:** The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

**Body SAR:** The SAR limit set by the FCC is 1.6W/Kg. For body worn operation, this device has been tested and meets the FCC RF exposure guidelines for use with an accessory that contains no metal and be positioned a minimum of 0 cm from the body.

**Head SAR:** This device complies with FCC radiation exposure limits set forth for an uncontrolled environment.

The equipment should be installed and operated with minimum distance 0 cm between the radiator & your body.

High power radars are allocated as primary users of the 5.25 to 5.35 GHz and 5.65 to 5.85 GHz bands.

These radar stations can cause interference with and/or damage this device.

No configuration controls are provided for this wireless equipment allowing any change in the frequency of operations outside the FCC grant of authorization for US operation according to Part 15.407 of the FCC rules.



■ This symbol, affixed to the product or its packaging, indicates that the product must not be processed with household waste. It must be brought to an electric and electronic waste collection point for recycling and disposal. By the appropriate disposal of this product you also help in preventing potentially negative consequences for the environment and human health. The recycling of materials helps preserve our natural resources. For further information regarding the recycling of this product, please contact your municipality, local waste disposal centre or the store where the product was purchased.

### **Accessories**

Please check the product box for the following items:


- Epaper×1
- USB Cable×1
- Writing Pen×1
- Leather Sheath×1

## Precautions For First Use

1. When using it for the first time, please use the 5V/1.5A power adapter or the USB port of the computer to charge the tablet until the indicator light turns green.
2. Please make sure your ePaper can connect to the wireless network properly.
3. When starting up for the first time, please follow the boot guide to perform operations such as networking.

## Appearance Introduction

Please be familiar with the device interface and keys before use.



## Instructions For Use



### USB Type-C

Charging: You can use the data cable to charge the Smart Note through the power adapter or the USB interface of the computer. It is recommended to use a 5V/1.5A power adapter or mobile power supply.

When charging, the indicator light turns red and the screen indicates that charging is in progress; when fully charged, the indicator light turns green and the screen indicates that it is fully charged.



### Power Button

Power on/off: Long press the key to power on/off.

Standby: Short press the power button to standby/wake up.

Fingerprint recognition: After the system sets fingerprint recognition, it can be awakened by light touch.



### Boot Guide

Press and hold the power button for a new machine, and set up according to the instruction manual after turning on the machine (it is recommended to operate the machine while the machine is charging when it is turned on for the first time).



### Service Support

When turning on the device for the first time, users need to read the instruction manual carefully. After confirming the precautions, you can log in to the [WWW.MAXHUB.COM](http://WWW.MAXHUB.COM) webpage to use the multi-terminal file transfer service.



### Firmware Upgrade

Make sure that the machine is connected to the Internet, and when there is a new version of the firmware after it is turned on or cancels standby, the system will automatically prompt the user to upgrade.

# MAXHUB

## Documents / Resources



[MAXHUB SN03 ePaper SmartNote](#) [pdf] User Manual  
SN03 ePaper SmartNote, SN03, ePaper SmartNote, SmartNote

## References

- [MAXHUB® æ—1ç1/2‘ç«™-è§!æŽšä\\_€ä1/2“æœº-æ™ºèf1/2ä1/4šè®ä13æ¿ç3»ç»Ÿ-ç”µè.,‘æŠ•â±-65â\\_è§!æ‘\\_ä\\_€ä1/2“æœºâžšâ°‘é’±](#)
- [User Manual](#)