



MiFitness Gr7 Console Kit Installation Guide

[Home](#) » [MiFitness](#) » MiFitness Gr7 Console Kit Installation Guide 

Contents

1

MiFitness Gr7 Console Kit

2

Product Information

3

Product Usage Instructions

4

Installation Instructions

5

Documents / Resources



MiFitness Gr7 Console Kit



Product Information

The Console Kit is designed for use with the Gr7 model. It includes a sender, sensor board, speed sensor cable, and batteries for the console. Please note that some parts included in the kit may not be used for the Gr7 model.

Product Usage Instructions

1. Step 1: Insert the battery into the sender.
2. Step 2: Attach the double Velcro mounts to the sender and plug in the sensor board.
3. Step 3: Remove the 4 screws holding the cover. Two on one side, and two more on the other side.
4. Step 4: Plug in the speed sensor cable into the sensor board.
5. Step 5: Mount the sender onto the frame, under the seat.
6. Step 6: Re-install the cover.
7. Step 7: Install the batteries into the console.
8. Step 8: Mount the console wherever preferred. It is recommended to remove the phone mount and replace it with the console.

Note: Some parts included in the kit, such as the magnet, are intended for use with other models (Gr6 & Gr3) and may not be used during the installation of this kit on the Gr7.

Installation Instructions

Installing console kit on Gr7

Step 1

- Please insert the battery into the sender.



Step 2

- Attach the double Velcro mounts to the sender and plug in sensor board.



Step 3

- Remove the 4 screws holding the cover. Two on one side, and two more on the other side.



Step 4

- Plug in the speed sensor cable into the sensor board.



Step 5

- Mount the sender on to the frame, under the seat.



Step 6

- Re-install the cover.

Step 7

- Install the batteries into the console.



Step 8

- You can mount the console wherever you prefer, but we recommend you remove the phone mount and replace it with the console.



There will be parts left over as this kit is for multiple models. Eg: The magnet is for Gr6 & Gr3.

Documents / Resources

<div><p>Installing console kit on Gr7</p><p>Step 1</p><p>Remove the console kit from the box.</p></div> <div><p>Step 2</p><p>Place the console kit on the back of the console and secure it with the screws.</p></div> <div>5</div>	<div><p>MiFitness Gr7 Console Kit [pdf] Installation Guide</p><p>Gr7, Gr6, Gr3, Gr7 Console Kit, Console Kit, Kit</p></div>
---	--