



MIGHTY BRIGHT REV200 LED Task Light User Guide

[Home](#) » [MIGHTY BRIGHT](#) » MIGHTY BRIGHT REV200 LED Task Light User Guide 



**LED Task Light & Magnifier
Assembly Instructions & User Guide**

Contents

1 ATTENTION:

2 ASSEMBLY STEPS

3 OPERATION

4 Documents / Resources

4.1 References

ATTENTION:

- Please review all the instructions and diagrams carefully before assembling the lamp. This will reduce assembly time and avoid damage.
- Do not force parts. Do not apply excessive force to wires during assembly.
- Remove all the packing materials before use.

WARNING:

- Do not look directly into the LED's and do not shine them into the eyes of others. As with other high intensity light sources, eye damage may occur.

ASSEMBLY STEPS

1. Remove the recyclable paper tray from the recyclable carton. Carefully remove the flexible arm with the magnifying Lamp from the tray. Gently lay them on a large, clean work surface.
2. Open the clip and insert into the notch in the weighted base. The light can be used with or without the base by clipping onto any suitable, stable surface.
3. Plug in the supplied AC adapter to the DC jack on the back of the clip. The lamp is now ready for use.

AC/DC Adapter specs:

- Input : 100-240VAC, 50 – 60 HZ
- Output : 12V DC 500mA
- The AC/DC jack is located on the back of the lamp base.


OPERATION

- The power switch is located on the top of the lamp head next to the magnifying lens. Press it once to turn on the light. Press again to cycle through the other brightness levels (High, Med, Low, Off). If the light fails to operate after turning the switch on, check that the AC power supply is fully plugged in.
- The color temperature selector is also located on the top of the lamp head. The touch-activated selector continuously cycles between cool (5,000K) and warm (3,000K) color temperatures. Press and hold the sensor to select the ideal color temperature for your needs.
- The flexible arm is intended as a convenient means of adjusting the lamp. Properly handled it will provide a lifetime of service. Do not abuse the flexible arm by bending it severely, abruptly, or forcefully.
- Do not attempt to remove or replace the LED's.

- Magnification: 5” diameter lens is 2X power with a 5X spot lens.
- Care: Clean the lens with a lint-free soft cloth or with a non-abrasive lens cloth. Never use a chemical cleanser.

Visit us at: www.mightybright.com
REV200

Documents / Resources

	MIGHTY BRIGHT REV200 LED Task Light [pdf] User Guide REV200 LED Task Light, REV200, LED Task Light, Task Light, Light
---	--

References

-  [Mighty Bright | Rechargeable Book Lights, Music Stand Lights & More](#)
- [User Manual](#)

Manuals+. [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.