



ORTECH TRAP-DS-SL Dual Size Lint Trap Instruction Manual

[Home](#) » [Ortech](#) » ORTECH TRAP-DS-SL Dual Size Lint Trap Instruction Manual 

Contents

- [1 ORTECH TRAP-DS-SL Dual Size Lint Trap](#)
- [2 OPERATION](#)
- [3 INSTALLATION GUIDE](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)



ORTECH TRAP-DS-SL Dual Size Lint Trap



OPERATION

WARNING


THE INSTALLATION MUST BE CARRIED OUT BY A QUALIFIED TECHNICIAN.

1. Easy to clean
2. Suitable for 4" and 5" diameter duct


CAUTION

PLEASE READ THE INSTRUCTION BEFORE COMMENCING INSTALLATION AND RETAIN FOR FUTURE REFERENCE. HVAC products can cause death or injury, or damage to property. If in any doubt about the installation or use of this product, consult a competent technician.

INSTALLATION GUIDE




1. Clean the dryer top surface properly before installation
2. Mark lint trap position on the dryer
3. Fix double-sided foam tape on the bottom surface of the lint trap to help the lint trap stick on the top dryer
4. Connect the ducts to the collars as shown on the left diagram



Clear the Lint Trap

Pull out the screen, clear the lint on the mesh, and then push the screen back to the housing ORTECH reserves the right to modify at any time, without notice, any or all of our product's features, designs, components and specifications to meet market changes.

Documents / Resources

	ORTECH TRAP-DS-SL Dual Size Lint Trap [pdf] Instruction Manual TRAP-DS-SL, Dual Size Lint Trap, Lint Trap, TRAP-DS-SL, Trap
---	--