



RETROFITLAB DRL Wire Harness Layout Instructions

[Home](#) » [RETROFITLAB](#) » RETROFITLAB DRL Wire Harness Layout Instructions 



RETROFITLAB
IMPROVED LIGHTING SYSTEM
DRL Wire Harness Layout
Instructions



Instructions
WIRE HARNESS LAYOUT – LED SHROUDS (DRL + TURN SIGNAL)

Contents

1 DRL Wire Harness


Layout

2 Documents / Resources

2.1 References

3 Related Posts

DRL Wire Harness Layout




1. Connect to positive (12v+) of the daytime running light
2. Connect to negative (-) of the daytime running light
3. Connect to positive (12v+) of the turn signal
4. Connect to the Positive (12V+) of the low-beam signal*



RETROFITLAB
IMPROVED LIGHTING SYSTEM
WWW.RETROFITLAB.COM

Documents / Resources

	RETROFITLAB DRL Wire Harness Layout [pdf] Instructions DRL Wire Harness Layout, DRL, Wire Harness Layout, Harness Layout, Layout
--	---

References

-  [Retrofitlab.com HID xenon led headlight upgrade and repair](#)